





www.tpro.com




Technical Pro
User Manual for WASP800UiBT Portable speaker

Front panel operation instruction




- 1.MIC: MIC. Input interface.
- 2.GUITAR INPUT: The guitar interface.
- 3.GUITAR VOL: To adjust the guitar volume.
- 4.MIC. VOL: To adjust the volume
- 5.ECHO: To adjust the reverberation of microphone.
- 6.TREBLE: To adjust the main pitch part.
- 7.BASS: To adjust the main bass part.
- 8.VOLUME: To adjust the main volume.
- 9.CARD: SD/MMC/MS card reader.
- 10.USB: USB reader.
11. Battery charge indicator LED light.
12. Battery need to change indicator LED light.
13. Battery work normally indicator LED light.
- 14.IR: Remote window
15. INPUT: Used to switch the USB/SD/bluetooth/IPOD reader and other external signal.
16. Next: Used to select next song, and if want to increase the volume,press the key in a few seconds.
17. PLAY/PAUSE key: Used to play or pause music.
18. PREVIOUS: Used to select front song, and if want to reduce the volume,press the key in a few seconds.
- 19.REPEAT: One song Repeat Key..
20. MP3 play condition indicator light.(Under the USB, SD IPOD AUX mode,LED light will be flashing fast, Under bluetooth mode,LED light will be flashing slowly.)
21. EQ: Piecewise frequency control
22. Ipod,iphone input




Rear panel operation instruction

- 1.External battery terminals.
- 2.Power switch: Used to open or close the speaker power.
- 3.External insurance stand: Used to replace the machine fuse.
- 4.Power socket: Used in power supply to the speaker.
- 5.Audio signal input: Used to connect various signal source.
- 6.AC voltage select switch.




Remote controller specification

- Power : Used to open or close the MP3 player power.
- PLAY/PAUSE key: Used to play or pause music.
- MODE: Used to switch the USB/SD/Bluetooth/IPOD reader and other external signal.
- PREVIOUS: Used to select front song
- Next: Used to select next song
- VOLUME+:Used to increase the MP3 player volume
- VOLUME-:Used to reduce the MP3 player volume
- 1 ~ 10+ Digital key:it can used to select repertoire directly or free combination when repertoire more than nine under USB/SD mode.



BATTERY INSTALLATION



FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.