




DT0719018

BAR CODE

DSSS-FH radio

Logic: 51410048

Honeywell

PWA 51306343-125

HW ☐ FW ☐

DSSS RADIO BD

ANT

DT0719005

BAR CODE

NO RF TestPoints

DSSS-FH
RADIO

Logic: 51410048
C14 [] C37 []
C27 [] L2 []
C36 []

DSSS RADIO BD

PWA 51306343-125

HW ☐ FW ☐

ANT

Honeywell



ETHERNET

LED PWR 5V INPUT

JTAG

SD IAI

750MAN

2W V8A7

AT91SAM7X256
AU
P1001 A
Atmel

TEST
MARG
EN
MARG
ERASE

BAR CODE

NO RF TestPoints

DSSS-FH
RADIO

Logic: 51410048
C14 [] C37 []
C27 [] L2 []
C36 []

DSSS RADIO BD

PWA 51306343-125

HW ☐ FW ☐

ANT

Honeywell

DT0719005

BAR CODE

NO RF TestPoints

Logic: 51410048


Honeywell

PWA 51306343-125

DSSS RADIO BD

HW ☐ FW ☐

ANT



PWB 51306342-100 Rev At1

PWB 51306342-100 Rev At1