



MEGA TOYS (HK) LTD.

ROOM 418-20, TOWER A, NEW MANDARIN PLAZA, 14 SCIENCE MUSEUM ROAD, TSIM SHA TSUI EAST, KOWLOON, HK
TEL: (852) 27211171 FAX: (852) 2721 1172

User Manual

Read this manual carefully before getting started on your car.

- 1) Unscrew battery lid and place 9V battery with correct polarity (+/-) into radio control unit. Screw battery lid.
- 2) Plug the charger into standard wall outlet. Connect the battery pack and charger by snapping together the jack and the socket tightly. After 4 hours, the battery pack will be warm. This condition is normal for fully charged batteries. To disconnect cables, press down on the clip and pull apart. Battery pack is ready for use. After use the battery pack will be hot! Wait until it cools before recharging. Recharging a warm or hot battery pack will greatly shorten battery life.
- 3) Make sure the ON/ OFF switch is in the " OFF" position on toy. Open the battery lid and place the battery pack inside properly. Plug the jack of the battery pack into the socket of the battery compartment. Close the battery lid. Turn on the "ON" switch to play.



NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS
EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY
TO OPERATE THE EQUIPMENT.