


3166 UHF RFID READER FCC LABELS

THE 3166 LABEL SET

The 3166 Label Set consists of an ID label and a small branding label. The ID label contains the reader part number, serial number, date of manufacture, country of manufacture and the relevant regulatory information and symbols for that part number. The Branding Label contains the TSL® logo and TSL website URL. A preview of the 3166 Label Set is shown below:



LOCATION OF THE ID LABEL

The ID label is located on the underside of the 3166 Reader.




ID Label can be found on the base of the 3166 UHF Reader




ID Label location

VARIANTS OF THE ID LABEL FOR EACH PART NUMBER



3166-AS1-US (with barcode) label



3166-AX1-US (without barcode) label

LOCATION OF THE BRANDING LABEL

The TSL branding label is located on the rear of the antenna housing, facing the user.



Branding Label