

**91455 Working:** Insert the battery or unit reset, the unit can continuously receive for 5 minutes, After 5 minutes, It can establish the staring time again according the channel for transmitter.

**91465 working:** Insert the battery or unit reset, the unit can determine the fixed firing time according to the channel choice, the channel 1 launches a time per 50 seconds, the channel 2 is 53 seconds, channel 3 is 56 seconds. Just press “TX” once, and it will launch once.