




## 1.6 User Manual




### About re-charge battery & led indicator

When battery power is low, this led turning to red color and flashing up to 3 minutes to remind you to re-charge the battery




Please plug the included USB cable into the USB drive for charging the battery



### Preparing for Use


#### Removing the Wireless USB Receiver



### Installing the Wireless USB Receiver

The wireless USB receiver is used like a regular USB flash drive. Plug the receiver directly into an available USB port of your notebook or computer. the drive is automatically recognized and installed.

Note:  
please always pay attention on the direction of the USB when plug into the USB drive



### Specifications

- RF transmission / Range : 2.4G / 30 meter ( in open space)
- USB interface : USB 2.0
- OS supported : Windows 7,XP, 2000,98 OS Mac 9.0 or later
- Green Wavelength :532nm
- Red Wavelength :630~680nm
- Power : Lithium battery
- Battery cycle life time : 500 times
- Battery burn time : > 2.5 hours
- Output power : CLIIIa < 5mW , CLII < 1mW
- Dimensions : 12.8(L) x 3.45 (W) x 2.7(H)cm
- Weight : 60g
- Available color : Black

### measures:

- + -Reorient or relocate the receiving antenna.
  - + -Increase the separation between the equipment and receiver.
  - + -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - + -Consult the dealer or an experienced radio/TV technician for help.
- You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.