




1.6 User Manual




About re-charge battery & led indicator

When battery power is low, this led turning to red color and flashing up to 3 minutes to remind you to re-charge the battery




Please plug the included USB cable into the USB drive for charging the battery



Preparing for Use


Removing the Wireless USB Receiver



Installing the Wireless USB Receiver

The wireless USB receiver is used like a regular USB flash drive. Plug the receiver directly into an available USB port of your notebook or computer. the drive is automatically recognized and installed.

Note:
please always pay attention on the direction of the USB when plug into the USB drive



Specifications

- RF transmission / Range : 2.4G / 30 meter (in open space)
- USB interface : USB 2.0
- OS supported : Windows 7,XP, 2000,98
OS Mac 9.0 or later
- Green Wavelength :532nm
- Red Wavelength :630~680nm
- Power : Lithium battery
- Battery cycle life time : 500 times
- Battery burn time : > 2.5 hours
- Output power : CLIIIa < 5mW , CLII < 1mW
- Dimensions : 12.8(L) x 3.45 (W) x 2.7(H)cm
- Weight : 60g
- Available color : Black

measures:

- + -Reorient or relocate the receiving antenna.
 - + -Increase the separation between the equipment and receiver.
 - + -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - + -Consult the dealer or an experienced radio/TV technician for help.
- You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.