


GAMESTERGEAR

**Falcon BT210
Bluetooth Headset Manual**

Feature




TECHNICAL SPECIFICATIONS


Acoustic Design:	Closed Back
Frequency Response:	20Hz - 20kHz
Driver:	57 mm @ 32 ohms
Bass Enhance Driver:	30 mm @ 8 ohms
Sensitivity:	112dB SPL, 1mW @ 1kHz
Mic Type:	Built-In Mic
Mic Frequency Response:	70Hz - 15kHz
Connector Type:	3.5mm for Line In

Package Contents

Falcon BT210 Headset




3.5mm Audio Cable




Micro USB Charge Cable

Control Dongle




- 1. Bass Level
- 2. Volume Level
- 3. Multi-Function Button
- 4. NFC



- 5. 3.5mm Audio Line In
- 6. Factory Reset
- 7. Built-in Mic
- 8. USB Charge Port

Optional Wired Mode


The headphone can also work in wired mode. Just plug in the 3.5mm cable into the Line In and the other end to your audio device. When in wired mode, the rumble effect will be disabled.



Turning On/Off

Push and hold the MFB for 3 seconds to turn the headphone on. A beeping sound will be made and the LED will turn red (On). Push and hold for 5 or more seconds to turn the headphone off.


Pairing with BT Device



When the headphone is on, push and hold the MFB for 5 or more seconds until the LED flashes red and blue. Navigate to your mobile phone or Bluetooth device and choose the Falcon BT210 device. A beep will indicate a connection has been established. The red LED will light up when the headphone is connected to a BT device.


Pairing with NFC

With the headphone on, touch the NFC enabled phone to the left side of the headphone. The phone and headphone will automatically pair together with a beep indicating it is being paired.




Volume and Song control

Push the + and - buttons for volume control. Push and hold the volume + or - button for 2 seconds for the next/previous track. Press the MFB button to pause/play the song.




Charging the Headphone

Connect the Micro-USB cable to the USB charge port and the other end of the cable into the USB port of your PC. When the headset is charging, the GamesterGear logos will glow blue. A full charge will take approximately two hours.




Answering Calls



When listening to music, push the MFB button to answer incoming calls. Push the button again to end the call. Push MFB twice to redial the previous number.

Factory Reset

Use a thin pointed object to insert into the hole. This will shutdown the headphone, and return the headphone to the manufacturer's default mode.



Maintenance

Do not expose headphones to extreme temperatures. Wipe the headphones and head-band with a mild antiseptic to avoid infection. Do not use alcohol-based disinfectants.

Safety Notice

To avoid potential damage to the device, always disconnect all cables before transporting it.

WARNING: Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time, so it is important to keep the volume at a safe level. Over time, your ears adapt to loud volume levels, so a level that may not cause initial discomfort can still damage your hearing. If you experience ringing in your ears after listening with the headset, it means the volume is set too high. The higher the volume is set, the less time it takes to affect your hearing. Be sure to listen at moderate levels.

Tips:

- Before placing a headset on your ears, turn the volume down completely, then slowly increase it to a comfortable level.
- Turn down the volume if you can't hear people near you speaking.
- Avoid turning up the volume to block out noisy surroundings.

Cautions

Do not make any modifications to the system or accessories. Unauthorized alterations may compromise safety, regulatory compliance, system performance, and may void the warranty

Operate this product within the temperature range of -4°F to 113°F (-20°C to 45°C) only. Damage caused by use outside of that range may not be covered by the warranty

Check and follow local laws regarding use of a mobile phone and headset/headphones while operating any vehicle or using equipment that requires your full attention. If you use the headset/headphones while engaging in any such activity, be sure to focus on safety.

Limited 1 Year Warranty

GamesterGear hereby warrants that this product will be free from defects in materials and workmanship for a period of one year from the date of purchase. GamesterGear will repair or replace the defective product and promptly return it to you. You should retain proof of purchase to validate the purchase date and return it with any warranty claim.

If you believe this product is defective within the warranty period, carefully repack the unit, insure it, and return it postage prepaid.

For return RMA and address, please visit www.gamestergear.com.

Customer Service

For additional help in solving problems, please visit www.gamestergear.com for online support.

FCC Warning

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Copyright © 2013 GamesterGear All Rights Reserved. No part of this document may be reproduced without prior written consent from GamesterGear. The GamesterGear logo, is a registered trademark of GamesterGear, Inc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. All other trademarks are properties of their respective owners and are hereby acknowledged. Made in China.