

GUARANTEED NEVER TO HURT OR FALL OUT



1 Insert sound tunnel.

2 Twist into place.



For a Getting Started video featuring TwistLock® in action, scan the QR code or visit yurbuds.com/inspire-twistlock

Our earbuds fit differently than other brands in that they are designed to fill the bowl of your ear with the sound tunnel extending down into your ear canal. They are not meant to be pushed down into the ear canal. The back of the bud should brace lightly against the back of the bowl of your ear.

FIT ENHancers TO EARPHONE



- 1 Wrap left enhancer around left earphone. Repeat for right side.



- 2 Start with the left bud and rotate sound tunnel between 3-4 o'clock position. Adjust for comfort.



- 3 Repeat with the right bud and rotate sound tunnel between 8-9 o'clock position. Adjust for comfort.

TO CLEAN ENHancers: Remove & wash with warm soapy water

NEED ANOTHER SIZE?



If the earbuds are not perfect, send us your picture for a FREE personalized fit. Take a photo of your current earbuds in your ear and email it to orders@yurbuds.com. yurbuds will send you the correct size for free, or exchange your model for a better-fitting option.

CONTACT US:

900 Spruce St. Suite 550
St. Louis, MO 63102, USA
www.yurbuds.com/contact

CALL US TOLL FREE:

(888)YUR-BUDI or
(888)987-2831

PRODUCT RETURNS: Please contact yurbuds for customer support before returning to store.

LIFETIME YURBUDS WARRANTY

yurbuds® purchased from authorized retailers are warranted against defects in materials and workmanship for the lifetime of the product. If a defect exists, yurbuds®, at its discretion and to the extent permitted by law will (1) repair the product at no charge, or (2) replace the product if it is irreparable. This warranty excludes damage resulting from abuse, accident, modifications or other causes that are not defects in materials and workmanship. THIS WARRANTY DOES NOT AFFECT YOUR STATUTORY RIGHTS. Visit yurbuds.com for our complete product warranty policy and register your product.

The use of mobile devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. For details on GUARANTEED NEVER TO FALL OUT see yurbuds.com/legal.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: a) Reorient or relocate the receiving antenna. b) Increase the separation between the equipment and receiver. c) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. d) Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: I. This device may not cause interference, and II. This device must accept any interference, including interference that may cause undesired operation of the device.

Cet émetteur portable avec son antenne est conforme aux limites d'exposition RF de la FCC / IC pour la population générale / exposition non contrôlée. Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: I) cet appareil ne doit pas provoquer d'interférences et 2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.

Model: 30004
QDID: B019076

DUAL PURPOSE EARPHONES



STEREO FOR SOUND

Use both earphones for a premium listening experience while being active.



GYM



HOME



OFFICE



MONO FOR MOBILITY

For easy, on-the-go use detach the second earphone and experience single-ear sound.



CAR



TRAVEL



OUTDOOR ACTIVITIES

POWER & PAIR

POWERING ON/OFF

- 1 Press and Hold the  Power Button.

 GREEN FLASH WITH AUDIBLE ALERT:
Power on, Not Paired
 EXTENDED BLUE FLASH WITH AUDIBLE
ALERT: Powered Off

PAIRING

- 2 Begin with your Bluetooth device powered on and in search mode.

- 3 Press and hold  Pairing Button.

- 4 Select "yurbuds Hybrid Wireless" on your device.

  BLUE & GREEN FLASH: Pairing Mode
 BLUE FLASH: Power on, Paired

MUSIC & CALLS

TRACK

Pause/Play:
1 Click

Next Track:
Double Press

Previous:
Long Press

CALL

Answer/End Calls:
1 Click

Voice Activation*:
2 Clicks

Redial:
Long Press

VOLUME

Volume Down:
1 Click

Volume Up:
1 Click



*Compatible with iOS only; Commands are not operational when listening to music

CHARGE

- 1 Locate the charging port at the side of the right earphone.

- 2 Lift cover for USB charging port

- 3 Plug in device with the provided charging cable



 FLASHING GREEN: Indicates Charging
 SOLID GREEN: Indicates Fully Charged

CHARGE STATUS

► On-Screen Indicator* shows level of charge



AUDIBLE ALERTS

Status provided once when battery is low



yurbuds®

CONNECT WITH US:
   



FOR MORE INSTRUCTIONAL DETAILS FOR YURBUDS HYBRID WIRELESS, PLEASE VISIT YURBUDS.COM