

7. SETUP PHOTOS

7.1. MASTER CONFIGURATION


DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP





7.2. SLAVE CONFIGURATION

DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP



DFS BACK PHOTO



END OF REPORT