

QUICK INSTALLATION GUIDE

Congratulations! You have just purchased E-Blocks®, a Positivo Informática product developed by a team of world-renowned experts who have been teaching English as a foreign language to young learners worldwide for many years. E-Blocks® is produced with high quality components.

Please check if your E-Blocks® kit contains the following items:

- E-Blocks® portable panel
- E-Blocks® cushioned mat
- E-Blocks® plastic cover
- E-Blocks® monitor base
- USB cable
- E-Blocks® Level 1 kit:
 - 88 red blocks with an E-Blocks® red bag
 - E-Blocks® Level 1 Software (with flash cards and Activities Summary available on pdf files)
 - E-Blocks® Level 1 Teacher's Guide including two Audio CDs (US/UK)

Connecting E-Blocks® to your computer:



- 1st**
- Attach one end of the USB cable to E-Blocks® panel. Do not put too much pressure on the plug or it might get damaged.



- 2nd**
- Attach the other end of the USB cable to the computer while **your operation system (Windows or Mac OS)** is running. If you are using **Mac OS, Windows 2000 or Windows XP**, administrator rights are required to install E-Blocks® properly.
 - NOTE:** Do not attach E-Blocks® to a USB HUB, as this can cause panel malfunction.




- 3rd**
- Windows **your operation system (Windows or Mac OS)** should automatically detect the new USB device. In this case, go to step 7. In some cases, Windows 98 will require a driver for Human Interaction Device (HID). If this happens, Windows "Add New Hardware" Wizard will start. Click on "Next".



- 4th**
- Follow the instructions on the screen and select **SEARCH FOR THE BEST DRIVER FOR YOUR DEVICE (RECOMMENDED)**. Then, click "Next".



- 5th**
- If necessary, check **Specify Location**. Click on "Browse" and locate **C:\Windows\system**. Click "OK" and then click "Next".



- 6th**
- Now Windows will locate the driver. Click "Next". Windows will then perform the driver installation and notify you when the installation is complete. Click "Finish".



- 7th**
- Install E-Blocks® Software by following the instructions on your E-Blocks® CD.

This product has a 12-month warranty starting from the original date stated on your purchase receipt. Therefore, the end user must keep a copy of the purchase receipt in a safe place. Please, read the warranty information on the back of this guide. Should your E-Blocks® need repairing, you will find instructions at www.eblocks.net.

Hot Keys

Note that the E-Blocks® Software has Hot Keys which are designed to help the teacher navigate through some restricted areas (off-limits to students).

- Shift + F1 to choose the help language.
- Shift + F2 to open the virtual keyboard (which can be used instead of the blocks).
- Shift + F3 to place the song and the game icons on the navigation bar.
- Shift + F4 to open the student record form



POSITIVO
INFORMÁTICA

Care and Maintenance:

- Keep product away from foods and beverages.
- Clean with a slightly damp cloth (cold water).
- Do not use soap or detergent.
- Never submerge the product in water.
- Avoid exposing product to extreme temperatures.

WARNING: Plastic bags can be dangerous. To avoid danger of suffocation, keep the plastic bags away from babies and children.

WARNING: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.



Warranty Information

This Positivo Informática Ltda. product is warranted only to the original purchaser for a period of 12 months from the original purchase date, under normal use and service, against defective workmanship and material. This warranty is void if the product has been damaged by accident or unreasonable use, immersion in water, neglect, abuse or improper service, or other causes not arising out of defects in workmanship or materials. This warranty is valid only if the product is used on the computer or system specified on the product box or product website. Repair or replacement as provided under this warranty is the exclusive remedy of the purchaser. Positivo Informática shall not be liable for any incidental or consequential damages for breach of any express warranty on this product. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited to the duration of this warranty.

Please retain the dated sales receipt as evidence of the date of purchase. You will need it for any warranty service.

During the warranty period, your product will either be repaired or replaced at Positivo Informática's option, when returned, shipping prepaid and with proof of purchase date as instructed by Positivo Informática's service representative. In the event that your product is replaced, the replacement will be covered under the original warranty or for 30 days, whichever is longer.

USA: In addition to the above-referenced warranty, some states do not allow the exclusion or limitation of incidental or consequential damages, or how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Canada: In addition to the above-referenced warranty, some provinces do not allow limitations on how long an implied warranty lasts, or the exclusion of incidental or consequential damages, so the above limitations do not apply to you. You may also have other rights, which vary from province to province.

UK: In addition to the above-referenced warranty, some provinces do not allow limitations on how long an implied warranty lasts, or the exclusion of incidental or consequential damages, so the above limitations do not apply to you. You may also have other rights under UK law, which this warranty does not limit.

FCC ID: SD6-012933

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Section 15.21

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Section 15.19:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.

E-BLOCKS® and the E-Blocks® Logo are registered trademarks of Positivo Informática Ltda.
© 2004 Positivo Informática Ltda. All rights reserved. Patent pending.

For ages 4–10 years



Falta
Texto fcc
nononono
nononono
nononono



For more information about CLRN
California leonine resource network
please visit www.clrn.org

