








8350-0392-01
WO.33356



ATTACHMENT
05FA3
REV. A

SENSOR1 C
SENSOR2 C
SENSOR3 C

RTD
RTD
RTD

RTD SENSE/EXT IN
RTD RETURN
SHIELD/GND

RTD EXC

RTD SENSE/EXT IN
RTD RETURN
SHIELD/GND

RTD EXC

RTD SENSE/EXT IN
RTD RETURN
SHIELD/GND

RTD EXC

RTD SENSE/EXT IN
RTD RETURN
SHIELD/GND

RTD EXC

RTD SENSE/EXT IN
RTD RETURN
SHIELD/GND

RTD EXC

RTD SENSE/EXT IN
RTD RETURN
SHIELD/GND

RTD EXC


RTD SENSE/EXT IN
RTD RETURN
SHIELD/GND


RTD EXC

8160-0391-03
WO 33422

Crossbow
MPR600
8350-0383-01
32816/071206







CE-A-36D8-0E01-0079

SENSOR1 CT
SENSOR2 CT
SENSOR3 CT

RTD
RTD
RTD

+5V GND PC_RX PC_TX RCD SENSE/EXT

D15 D12 D11

SW1
RESET

RTD RETURN
RTD EX
SHIELD/G

RTD RETURN
RTD EX
SHIELD/G

RTD RETURN
RTD EX
SHIELD/G

SENSOR1

SENSOR2

SENSOR3

W144004
CROSSBAR
© 2006
7200-0311-03 REV A

WTP400CA
CROSSFLOW
© 2006

7200-0371-03 REV. 1

RTD
RTD
RTD

SW2

SENSOR1 C
SENSOR2 C
SENSOR3 C

SENSOR1

J1
RTD EXC

RTD SENSE/EXT IN

RTD RETURN

SHIELD/GND

SENSOR2

J2
EXC

RTD SENSE/EXT IN

RTD RETURN

SHIELD/GND

SENSOR3

J3
EXC

RTD SENSE/EXT IN

RTD RETURN

SHIELD/GND

TPT

05FA-36D8-0E01-0079

+5V GND PC_RX PC_TX RTD SENSE/EXT IN

J4

RTD SENSE/EXT IN

RTD RETURN

RESET

RTD

C

LED

DI2

DI1

SW1

