




Syncomm Confidential

DC5V TP12 TP
 USBP TP13 TP
 USBN TP14 TP
 PGND TP15 TP




Option: (RF_EN Trigger function by software define).

- 1.SW7=Tact Switch , R94=10K , R95=NC
Push Switch , TX change state (ON / OFF).
- 2.SW7=NC , R94=10K , R95=NC
During charging , TX -> OFF
- 3.SW7=NC , R94=NC , R95=10K
During charging , TX -> ON




Option (Charge circuit)





File	CHARGE_POWER / GND
Size	Document Number
C	<Doc>
Date	Friday, March 14, 2008
Sheet	3 of 5
Rev	<Rev>
Code	<Code>

Syncomm Confidential





Title			ADC_AK5357
Size	Document Number	Rev	
B	<Doc>	<Rev Code>	
Date:	Friday, March 14, 2008	Sheet	4 of 5

Syncomm Confidential



Option: (RF_EN Trigger function by software define).

- 1.SW7=Tact Switch , R94=10K , R95=NC
Push Switch , TX change state (ON / OFF).
- 2.SW7=NC , R94=10K , R95=NC
During charging , TX -> OFF
- 3.SW7=NC , R94=NC , R95=10K
During charging , TX -> ON



Option (Charge circuit)

