


QWIZDOM Q6 REMOTE

Menu/Power: Press and hold to turn remote on/off. Press to view menu options: *Help, Search, Sess. ID, User ID, and Exit.*

Enter: Press to submit commands from LCD menu choices.

Directional Arrows: Press to navigate between menu options, answer choices, and questions.

Symbols: Select to enter fraction, superscript, and subscript answers.



Q#: Displays the current question number.

ID#: Displays the remote ID number.

Battery Power: Appears when battery is low.

Multi-function: Function changes depending on above LCD display.

Right/Wrong Feedback: Indicates the submitted response was correct (✓), incorrect (✗), or received (✓✗).

Delete: Press to delete the last character or change answer.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Common Remote LCD Displays

Find Net Remote is searching for the host.

Qwizdom Remote has found the host and is ready for a question slide.

Push Key Remote is idle. Press any key, except "Menu," to reactivate.

Help First available Menu option. Press "Send" to ask for help privately or scroll right to "Exit" and press "Send."

Inactive Remote senses the host is not in use, or does not recognize the session. If remote remains inactive after starting a presentation, press "Menu," scroll right to "Sess.ID," and press "Send." When prompted, reenter the session ID and press "Send" again.

No Net Remote cannot find the host. Reenter the "Session ID." If "No Net" continues, reenter "User ID" and "Session ID."

Denied User denied due to incorrect Session ID, User ID, or a duplicate ID.

Loading Loading an answer key; may take a few moments.

Activity Requesting an Answer Key activity number. Prompt only appears when multiple test versions are being presented. Activity numbers should be noted on the test sheets before presenting; numbers cannot be viewed while in presentation mode.

CAUTION:

Any changes of modifications not expressly approved by the grantee of this device could void the users authority to operate the equipment.

This manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE

THIS MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.