

miffy x MPOW

miffy TD17 真无线蓝牙耳机说明书

产品介绍

miffy TD17是一款真无线-HIFI级音效的蓝牙耳机，外观精致可爱，机身小巧便携，符合人体工程学-久戴不痛。充电快，机身续航时间长！是运动健身、图书自习、日常通勤等...的完美选择对象。

产品结构

产品操作

功能	操作	指示灯	提示音
开机	1.耳机充电仓合盖,充电仓触点接触充电线2.0秒;耳机触点接触充电线3秒开机。	自灯长亮1秒后灭	POWER ON
关机	1.耳机放入充电仓,耳机触点接触充电线2.0秒;耳机触点接触充电线3秒关机。	自灯长亮1秒后灭	POWER OFF
左右耳机配对	1.耳机放入充电仓,耳机触点接触充电线2.0秒;耳机触点接触充电线3秒开机。	自灯长亮1秒后灭	POWER ON
手机连接配对	长按充电仓触点,当听到“连接成功”提示音后,“miffy TD17连接成功”提示音。	自灯双闪	English
挂起/暂停	最长待机下,单击耳机触点触碰区	/	/
上一曲	最长待机下,三击(1)边耳机触点区	/	/
下一曲	最长待机下,三击(2)边耳机触点区	/	/
增加音量	多指触点下,双击(1)边耳机触点区	/	/
减小音量	多指触点下,双击(2)边耳机触点区	/	/
语音助手	在最长待机状态下,长按(2)边耳机触点区	/	/

接听来电	来电状态下,单击任意耳机触点区	/	/
拒绝来电	通话状态下,单击任意耳机触点区	/	/
挂断电话	通话状态下,单击任意耳机触点区	/	/
低电量警报	检测到低电量时,每间隔1分钟会有提示音。当电量低于10%时,每间隔1分钟会有提示音。	电池低电量	Battery in low
自动回连	蓝牙成功连接时,耳机长亮自灯。	/	/
耳机光效展示	耳机长亮黄色光效。	耳机长亮黄色光效。	耳机长亮红色光效。
耳机光效展示	耳机长亮黄色光效。	耳机长亮黄色光效。	耳机长亮红色光效。

安全须知

使用本产品前请仔细读所有提示资讯,如果发现真无线蓝牙耳机有异味、漏液、鼓胀等异常现象请立即停止使用,并将本产品置于远离人群的安全地方,以免发生意外。此外:

- 1.请选择USB适配器,确保其具有安规认证;
- 2.切勿自行打开或机械拆卸产品。
- 3.请勿将移动电源置于沙发、床、汽车座椅等易升温不易散热的位置进行充电。
- 4.请远离潮湿环境,勿将产品进行剧烈的摔打、撞击摩擦,以免造成产品凹陷、穿孔、开裂等损坏及其它异常现象;
- 5.将产品置于儿童不易拿到的地方,以免发生意外;
- 6.充电完成后请断开设备连接;

耳机参数

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Gr. VI)	多溴联苯(PBB)	多溴二苯醚(PBDE)
主机	×	○	○	○	○	○
配件	×	○	○	○	○	○

产品中有害物质含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Gr. VI)	多溴联苯(PBB)	多溴二苯醚(PBDE)
耳机	○	○	○	○	○	○

保修卡

多谢选购MPOW产品,本产品出厂时符合相关规定标准并经过演进审核。
我司为客户提供自购买之日起十二个月内的保修服务。需要保修服务时,请出示本正品发票正本,并详细填写保修相关内容。保修服务只限于产品在正常使状态下出现的质量问题。不适用于因人为损坏、粗暴操作、不正确的使用、人为伤害、外力挤压、人为拆装修改、过度高温、外壳人为磨损或不可抗力的损坏(如地震、火灾、火灾、台风或战争等),保修逾期的,保修服务将收取相应的维修费。

RoHS

—

扫描关注

品名:

型号:

购买日期:

销售点:

客户姓名:

网购名:

移动电话:

联系地址:

邮政编码:

故障描述:

注:MPOW所有对上述所有条件之最终裁决权,并随时对条款和条件作出更改,而无需另行通知。

保修卡须知:我司为客户提供标准一年保修。对于任何直接、间接、其他处理不当或无视说明书所含信息而引起的损害或连带损坏,我司不承担责任。

10

在中华人民共和国境内销售的电子电气产品必须标识此标志,标志内的数字代表在正常的使用状态下的产品的环保使用期限。

请仔细填写您的信息,请将此保修卡剪下,连同需维修产品一起寄回我公司维修中心。

miffy x MPOW

miffy TD17 INSTRUCTIONS

INTRODUCE

The miffy TD17 is a Bluetooth headset with real wireless HIFI sound effects. It has a delicate and lovely appearance, a small and portable body, and is ergonomic – it will not hurt if you take it for a long time. Fast charging, long battery life! It is the perfect choice for sports and fitness, book self-study, daily commuting, etc.

PRODUCT MIX

OPERATION

Function	operation	Indicator light	Clew tone
ON	1.The headset is in charging state, touch the touch point on the earbuds for 1 second to turn on the earbuds.	Power on	“Maximum prompt tone” Dongdong
OFF	1.The headset is in charging state, touch the touch point on the earbuds for 1 second to turn off the earbuds.	Power off	“Prompt tone” beep
Pairing/End pairing/Reconnection	For the first pairing, touch the touch point on the earbuds for 3 seconds, then touch the touch point on the earbuds again for 3 seconds. The earbuds will automatically disconnect from the previous connection and connect to the new connection.	Power on/ pairing mode	“Clew tone”
iPhone connection	After the phone is paired, touch the touch point on the earbuds for 3 seconds, then touch the touch point on the earbuds again for 3 seconds. The earbuds will automatically connect to the phone.	Flash when light is on	English/Chinese
Play/Pause	In the music state, click the touch point on the earbuds, the earbuds will play/pause the music.	/	/
Previous song	In the music state, triple click the touch point on the earbuds, the earbuds will play the previous song.	/	/

Next	Under the music state, triple click the touch point on the earbuds.	/	/
Volume Up	Under the music state, double click the touch point on the earbuds.	/	“Maximum prompt tone” Dongdong
Volume Down	Under the music state, double click the touch point on the earbuds.	/	/
Language	Under the connection mode, touch the touch point on the earbuds for 3 seconds, then touch the touch point on the earbuds again for 3 seconds. The earbuds will automatically switch the language.	/	/
Answer the (iPhone)	Click the touch point on the earbuds when the phone is ringing.	/	/
Reject calls	Click the touch point on the earbuds when the phone is ringing.	/	/
Hang up	Click the touch point on the earbuds when the phone is hanging up.	/	/
Low battery alarm	When the battery level of the earbuds is low, the earbuds will automatically remind you to charge.	Battery in low	please charge
Automatic reconnection	The earbuds will automatically connect to the phone when you turn on the phone.	/	/
Headset lighting display	The headset will automatically turn on the light when you charge the headset.	/	/

SAFETY INSTRUCTIONS

Before using this product, please read all the tips carefully. If you find any abnormal phenomenon such as odor, leakage, swelling, etc. on the bluetooth wireless earbuds, please stop using it immediately and take it to a safe place away from people to avoid accidents. In addition:

1. Please select USB adapter carefully to ensure that the adapter has safety certification.
2. Do not open or mechanically disassemble the product.
3. Do not place the mobile power supply in the sofa, bed, car seat and other places where it is easy to heat up and not easy to heat up for charging.
4. Please keep away from damp environment, and do not throw, impact or rub the product violently to avoid product depression, perforation, cracking, deformation, corrosion and other abnormal phenomena;
5. Place the product in a place that is not easily accessible to children to avoid accidents;
6. Please disconnect the device after charging;

PARAMETER

Product name : miffy earbuds

model : miffy TD17

Input: 5V=250mA

Headphone battery cap Acity: 30mAh*2

Charging compartment Battery capacity: 300mAh

Bluetooth transmission distance : 10m

Charging interface: Type-C

Headphone usage time : ~4 hour

Single charging time of headset : ~1 hour

Charging time of headset compartment: ~1.5 hour

Thank you for your purchase miffy x MPOW product MPOW warranties product has been tested and proved to be qualified for delivery in conformity with standard. This Limited Warranty for the product shall last for twelve (12) months from the date of original purchase. This original warranty card and original invoice must be presented at the time you require service. The warranty period begins on the date of original purchase and ends on the date of the twelfth (12th) month following the date of original purchase. This warranty is valid only if the product is used for the purpose for which it was designed. It does not apply to damage or loss caused by negligence; physical abuse; misuse; accident; exposure to moisture; dampness or extreme temperatures; unauthorized modifications; unauthorized opening or repair; forces of nature; other reasons beyond the reasonable control of MPOW.

In case of when the warranty does not apply, the customer shall be responsible for sending the defective product to and collecting the repaired or replaced product from the service center.

MPOW

reserves the right to amend and the final interpretation of the above terms without prior notice.

WARRANTY NOTE: The product has standard one-year warranty. For any direct, indirect, incidental or consequential damages other damages caused by improper handling or disregard of the information contained in this manual, we assume no liability

WARRANTY CARD

Product Name: _____

Model No.: _____

Purchase Date: _____

Dealer Shop: _____

Customer Name: _____

Order No./Website Name: _____

Mobile Phone No.: _____

Contact Addr.: _____

Postal Code: _____

<div data-bbox="734

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meeel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.