


2/24/05

MEMO TO: Sharon Hoffman - TIMCO

FROM: Mark Kilbourne - Mr. Butler Co.

To operate the remote transmitter, press the button once to lock
and once to unlock.

To change battery, loosen screw on cover.



Warning statement: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: 1.) This device may not cause harmful interference, and 2.) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.