

SAMSUNG

 Bluetooth®

Bluetooth GPS Speaker

ACSP100BBE

English

» ***Getting started***

1. Unpacking	3
2. Product Overview	3
3. Button Functions	4
4. Installing the product	6
5. Indicator light status	7

» ***Before using the product***

6. Turning On or Off	8
7. Pairing the product with a compatible phone	8
8. Connecting after completing the pairing	10

» ***Using the product***

9. Making and answering a call	11
10. Rejecting a call	12
11. Switching the call between phone and the product	12
12. Activating Call-Waiting function	12
13. Activating 3-way call function	13
14. Adjusting the volume	13
15. Muting an ongoing call	13
16. Using GPS Speaker function	14

» ***Care and Maintenance***

17. Storing the speaker	15
18. Frequently asked questions	15
19. Certification and safety approvals	17
20. Warranty and parts replacement	19
21. Correct Disposal of This Product	20
22. Glossary	21
23. Specifications	22



Thank you

Thank you for purchasing the Samsung Bluetooth GPS Speaker ACSP100BBE, we hope you will be delighted with its operation. Please read the instruction manual to get started and to make best use of the device's many features.



Drive safely

Using a mobile phone while driving creates a distraction to the driver which may increase the likelihood of an accident.

When using the phone while driving, keep conversations short and do not make notes or read documents. Before answering calls consider your circumstances. Pull off the road and park before making or answering calls when driving conditions require (e.g. bad weather, high traffic density, presence of children in the car, difficult junctions or manoeuvres.)

Remember, driving comes first, not the call!

Abide by local laws.



Check phone compatibility

The Samsung Bluetooth GPS Speaker ACSP100BBE is compatible with most **Bluetooth¹** (see **Glossary**) phones that are compliant with Bluetooth version 1.1 or higher specification and support **Hands-free profile, Headset profile and Serial port Profile²**. Ensure that your phone has Bluetooth capability by visiting your phone manufacturer's web site.

Getting Started

Explains what to remember for a proper use of your Bluetooth GPS Speaker.

1

Unpacking



Bluetooth
GPS Speaker



Car Adapter




Cradle



User Manual

2

Product Overview



3

Button Functions

Refer to **Before using the product** and **Using the product** sections for details about button functions.

**Talk Button**

Press to answer a call.

Press and hold for 2 seconds to connect to the phone after the pairing is completed.

Press in standby mode⁵ to redial the last dialed number.

Press and hold for 2 seconds to put current call on hold and answer a second call.

**End Button**

Press and hold for 2 seconds to end a call.

Press and hold for 2 seconds in standby mode to disconnect the phone.

Press and hold for 2 seconds when a call comes in to reject a call.

Press and hold for 3 seconds to power on/off.

**Function Button**

Press for 2 seconds while Call-Waiting is activated to activate 3-way call.

Press and hold for 3 seconds in idle mode to pair the speaker with the phone or GPS.



- The buttons detect the signal through magnetic sensor. Please make sure to press the buttons with hands until the sensor recognizes the signal. The product may malfunction if you press the buttons with plastics (Nonconductors) or press too shortly.



Side Function Button

	<p>Move left/right to adjust the volume. (8 Steps)</p>
	<p>Move left/right while pressing and holding to adjust the volume step by step automatically. (Unavailable when the GPS is activated)</p>
	<p>Press and hold for 3 seconds to switch the call to the product while talking on the phone. Press and hold for 3 seconds to switch the call to the phone while talking on the product.</p>
	<p>Press and hold for 2 seconds to mute the microphone while talking on the product. (To unmute, press or move left/right)</p>

4


Installing the product

This product does not have rechargeable battery. Please make sure to connect the speaker to the power source when using.



1. Fix the product on the sun visor in a car, then connect the car adapter to the car adapter connector on the product.

- Place the product on the proper spot within easy access of your voice.
- Fix the product firmly by using the clip on the back so that it is not dropped while driving.



2. Arrange the cables of the car charger and plug the adapter into the power socket in your car.

- The indicator light turns into BLUE-RED-PURPLE twice, then solid BLUE light is on if powered on when connected correctly.



- The product is available only within the distance of 10m. It may malfunction if the distance between the product and the phone is over 10m. So make sure not to be out of the distance limit when installing.
- Make sure to store the product with power off when not using.
- Use only Samsung-approved car adapter. Unauthorized adapter may cause an explosion or damage on the product.
- Always try to keep the battery at room temperature (0°C~+40°C).

5

Indicator light status

Refer to the table below to understand the present status and use the best of the product.

Speaker Status	Indicator Light Status
Power on	BLUE ➤ RED ➤ PURPLE light flashes twice in order
Power off	All LED lights are turned off
Pairing Mode	BLUE light is on (When ready to be paired)
Idle Mode	BLUE light flashes every 3 second (Disconnect Idle Mode)
	BLUE light flashes twice every 3 second (2 min. after Pairing Mode)
Stand-by Mode	BLUE light flashes every 6 second
Active Mode ⁶	BLUE light flashes twice every 6 second
GPS activated	BLUE light turns into PURPLE light if GPS is activated while using the speaker function