

FAMOUS CAR



Century  
**RC**  
**FAMOUS CAR**

使用说明书  
USE MENU



遥控车配有14.4V高品质1800毫安二插可充电电池。正常使用可达到五年寿命。请不要在近水、高温、潮湿的地方充电或存放。

充电时间为6-8小时，超过8小时不能再充电，否则会缩短电池的寿命。充电后从电源插座上拔下充电器。

The R/C car includes the 14.4V, 1800Ma, 2 socket quality chargeable battery. The battery can be used last for 5 years in normal case. Don't charge or keep the battery near the water, high temperature place and moisture place.

The charging time is about 6 - 8 hours, over 8 hours is not allowed, or it will shorten the battery life and take off the charger from the power socket when finish charging.



遥控车配有12V, 2600毫安二插可充电电池。请不要在近水、高温、潮湿的地方充电或存放。

充电时间为4-5小时，超过6小时不能再充电，否则会缩短电池的寿命。充电后从电源插座上拔下充电器。

The R/C car includes the 12V, 2600Ma, 2 socket quality battery. Don't charge or keep the battery near the water, high temperature place and moisture place.

The charging time is about 4 - 5 hours, over 6 hours is not allowed, or it will shorten the battery life and take off the charger from the power socket when finish charging.




充电时充电器指示灯亮有微发热，属正常现象，充电器配有温度保险开关，超过温度会自动断开。

The charger's light on and give out sick heat when charging is normal. The charger include the temperature insurance, it will cut off when over - heat.

## 电池电量指示灯

Battery energy indicator.




指示针到红线时，表示电量充足。指示针到绿线时，表示电量低、不足。指示针到黄线时，表示没有电量，不能继续使用，请更换新电池。

The indicator needle to the red line means the battery is full. When the needle to the green line means the battery exhausted. When the needle to the yellow line mean the battery is finished, can't use any more, need to replace the new battery.



将遥控器扳手向前推为前进，向后推为后退，右边扳手向右扭为右转，向左扭为左转。

Push the R/C unit's trigger forward, means drive forward; push backward means drive backward. Turn the right trigger to right means drive right - ward. Turn left means drive left.



### 方向调整器：

在行使过程中，遥控车不能直线行走，可用来调节。

Direction adjusting set: It can adjust the car when it can't drive straightly during driving.



遥控器不能使用封皮破损的电池。  
Do not use battery with broken wrap.



向下推打开遥控器电池盖，按正负极标记放入1.5V电池8节，按反方向上推合上电池盖。

Open the battery cover of the R/C control, put in the 1.5V battery 8 pcs according the polarity, then cover it.



遥控器需注意电池的正负极安装。  
Pay attention to the battery installment for the polarity.



请选择用普通高性能AA 1.5V电池。  
Choose large capacity AA alkaline batteries and high-performance Ni-MH rechargeable batteries.



将遥控器电源开关拨向ON方向为开。  
Dial the R/C control power switch to 'ON' to play.




充电方式①  
Charge Style①

注意充电器插头对号插入电池插座，  
电池极性不可接反。


Insert the plug of the charger into the socket according to the diagram, do pay attention the polarity of the battery.



充电方式②  
Charge Style②



注意插头座的配对位置对号插入  
充足电的电池，电池极性不可接反。  
The battery installment of the car body.  
Insert the full battery to the correct position of the socket according to the dia gram. And pay attention to the battery's polarity.



合上电池盖时将底盒上两个固定  
件拔向电池盖，以免遥控车行驶时电  
池掉落损坏。

换新电池前，应将钥匙开关扭向  
关闭位置。



先确认钥匙开关在关闭的位置。

Make sure that the key switch is on the 'off' position.

# 请认真阅读使用说明书

The motor is working normal.

购买L888遥控车，您的包装盒里含有下面的东西：

Purchase the L888 R/C car, the contents in your packing box are as follows:

遥控车  
R/C car



遥控器  
R/C control



说明书  
menu



充电器、接头  
charger, Connector



充电电池  
Recharge battery



充电电池  
Recharge battery



本产品原配件采用各种优质材料，配有敞篷、雨蓬两款可供选择，如有需要请到当地销售店重新购买。

The original parts of these products use every kind of good quality materials, and include the open car & normal car for your selection. If you have other need, please buy from your local shop.

雨蓬  
Awning



敞篷  
Open car



相同频道的遥控车，不能在同一区域使用，以免干扰失控。

Do not play R/C cars of same frequency in the same area in case of interference and out of control.



天线不要随意弯曲或指向他人，以免造成伤害。

Do not fold the antenna at random or point at others in case of injury.



不要在公路上和其他有危险的地方游戏，以免发生意外。

Don't play it on the street or at dangerous places in case of accident.



不要在水坑、有毛或线的地面、沙地、泥地等到不洁的地面行驶。


Do not run it where there is sump, ground with fur or string, or dirt ground such as sandlot or mud.



1 将电源开关的钥匙向右转，发动机有工作声音，尾灯亮，驾驶台灯亮，电流指示表亮。  
 2 遥控车前进行驶时，前进灯亮，往左转向时，左边前后转向转会闪闪发亮；右转向时，右边转向灯会亮；倒车时，倒车灯会亮。  
 3 在行驶过程中，当你停下车时，倒车，左右转向灯全亮，发动机会正常工作。

1 Turn the key of the power switch to the right, the motor start working. The end light is on.  
 2 When the R/C car drives forward the forwarding light on. When turn to left, the forward &backward light of the left will be twinkle. When turn to right, the turning light of the right will be on. When drives backward, the backward light will be on.  
 3 During driving, when you stop the car, drive backward, the left - right turning light will right turning light will.





# 1:5 Exquisite Radio Control Model

## 概述

欢迎您购买我公司生产的1比5 L888精致遥控模型车，相信您会发现本车有着特别的功能，操作简单又方便。

为让您更好地使用我公司生产的遥控车之前，敬请您仔细参阅使用说明书，以免产生危险或损坏。


模型遥控与遥控技术，因价格昂贵，一直只能在少数休闲阶层、模型爱好者得以应用，本公司经精心钻研、积多年之力，至现在以有多款精致模型遥控与比例遥控技术车，百姓化方面获得突破性进展，成功推出多种遥控技术与精致模型车，让您能以较低的价格就能享受到遥控技术与精致模型的高境界，为您带来无比的欢乐、全新的概念全新的感受。

## OUTLINE

Welcome you to purchase our products item no. L888 1:5 perfect R/C model car. We trust you will find that this car has the special functions, and it is easy to operate and be convenient to you.

For better using our products, do please study our menu carefully to avoid the dangerous and the damage.

For the expensive price of the model R/C and the R/C technology, it only used price of the model R/C and the R/C technology, it only used company have much careful research and wide experience for many years. Till now we get many kinds of perfect model R/C many years. Till now we get many kinds of perfect model R/C progress in making these kinds of cars to be public, and also command many kinds of R/C technology and perfect model car, and let you enjoy the high taste of the R/C technology and the perfect model in a lower price. It will bring you un - limit happiness and new idea & feelings.



专利号(ZLH):200430042968.8

专利号(ZLH):200430042967.3

专利号(ZLH):200420070946.7

# 产品信息反馈表

填表日期:

反馈地区:

遥控车外形评估	<input type="checkbox"/> 很好	<input type="checkbox"/> 普通	<input type="checkbox"/> 不行
遥控车质量评估	<input type="checkbox"/> 很好	<input type="checkbox"/> 普通	<input type="checkbox"/> 不行
遥控操作度	<input type="checkbox"/> 没问题	<input type="checkbox"/> 很好	<input type="checkbox"/> 操作困难
遥控车综合评估	<input type="checkbox"/> 很好	<input type="checkbox"/> 普通	<input type="checkbox"/> 不行

您对我公司的建议:

感谢您购买我公司产品，为了使我们产品更让您满意，请在使用后填写“产品信息反馈表”，并寄回您当地的经销商或直接与青松玩具有限公司联系。

产品名称	经销商盖章
购买日期	



青松玩具有限公司  
QINSONG TOYS INDUSTRIAL CO.,LTD.

The products' information feed back sheet

feed back area:

form date:

R/C car outlook remark:	<input type="checkbox"/> very good	<input type="checkbox"/> ordinary	<input type="checkbox"/> bad
R/C car quality remark	<input type="checkbox"/> very good	<input type="checkbox"/> ordinary	<input type="checkbox"/> bad
R/C operating degree	<input type="checkbox"/> no problem	<input type="checkbox"/> very good	<input type="checkbox"/> operating difficult
R/C car comprehensive remark	<input type="checkbox"/> very good	<input type="checkbox"/> ordinary	<input type="checkbox"/> bad

Your suggestion:

Thanks for your purchase QINSONG products, for your more satisfy with our products. Please write the 'products information feed back sheet' after using our products and send to the local supplier or direct contact with QINSONG TOYS.

PRODUCT NAME	SUPPLIER'S CHOP
PURCHASE DATE	



青松玩具有限公司  
QINSONG TOYS INDUSTRIAL CO.,LTD.

#### (一) 使用前注意事项:

- 请认真阅读使用说明书。
- 不要让电池短路，以免急剧发热而损坏。
- 电池漏液溅及皮肤会引起损伤，应马上以清水冲洗。
- 绝对不要将电池投水中、火中或分解电池。
- 不要在近水、高温、潮湿的地方充电或存放。
- 准备好必要的工具和备用电池。
- 选择宽阔安全无高压电干扰的场所。
- 先打开遥控器电源开关，再打开遥控车电源开关。

#### (二) 行驶中注意事项:

- 在室内使用时请将接收天线收回，避免碰坏；使用时，注意不要撞向玻璃、人，家具等。
- 不可用手触摸高速旋转的车轮及部件，以免受伤。
- 车速变慢应停止使用，因为电力不足，应更换新电池或者重新充电。

#### (三) 使用后注意事项:

- 先关闭遥控车电源开关，再关闭遥控器电源开关。
- 取出所有电池放在干燥的地方保存或充电。
- 应将车子上的泥土、沙子、污垢清除干净。
- 检查轮胎、螺丝有无松动、变形，电机有无异味。

#### (四) 常见问题:

- 大多数故障是因为电力不足和周边电波干扰所致，故应选择宽阔安全无高压电等电磁干扰的场所。

车的状态	原因	检查、纠正办法
车不能动	遥控器或车内没有电池	装入电池
	电池安装不正确	重新安装
	开关位置不正确	将开关拨向ON
车乱跑不听使唤	受电波妨碍	换场地
	同频道车同时使用	拉远距离或不同时使用
速度慢	电池充电不足	重新充电
	电池使用时间超过其寿命	更换新电池

#### (1) Notes before using:

- Please read the instruction carefully before using.
- Don't cause short circuit to the battery in case of damage resulted from rapid heat.
- The leakage of battery slopping over the skin will cause injury. Please rinse immediately.
- Don't charge or put the battery near water, heat or wet place.
- Prepare necessary tools and standby battery.
- Choose places where is commodious, safe and without interference of high voltage.
- First turn on the switch of the remote controller, and then turn on that of the R/C car. Readjust to zero at any time according to the change the voltage of the battery.

#### (2) Notes while running:

- Take back the receiving antenna when playing in indoors, to avoid damage. Do not bump to the glass people and furniture when playing.
- Do not touch the rapid-rolling wheels or parts lest being hurt. Please stop using the car if it slows down because it is lack of electricity.
- Please replace with new battery or recharge it.

#### (3) Notes after using:

- First turn off the switch of the R/C car, and then turn off that of the remote controller.
- Take out all the batteries and keep or charge them in a dry place.
- Clean out the earth, sand and dirt on the car.
- Check whether the tire and the screw become flexible or out of shape and whether the engine has got peculiar smell or not.

#### (4) Common Problems:

- Most of the malfunctions are caused by lack of electricity and the interference of the electric wave around, so you must choose the place that is commodious and safe and without interference of high voltage.

CONDIMONS OF CAR	CAUSE	CHECK AND REPAIR
THE CAR DOESN'T MOVE	NO BATTERIES IN THE REMOTE CONTROLLER.	PUT BATTERIES IN THE CONTROLLER.
	THE BATTERIES AREN'T INSTALLED CORRECTLY.	REINSTALL THEM.
	THE SWITCH IS OFF.	TURN ON THE SWITCH.
THE CAR IS OUT OF CONTROL	AFFECTED BY THE WAVE OF RADIO.	CHANGE FOR A PLACE OR WAIT.
	THERE IS ANOTHER SAME FREQUENCY CAR BEING USED.	
THE POWER RUNS OUTQUICKLY OR THE SPEED CAN'T BE LIFTED	THE POWER IS NOT ENOUGH.	RECHARGE THE BATTERY.
	THE LIFE OF BATTERY.	CHANGE FOR A NEW BATTERY.

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV  
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS  
EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY  
TO OPERATE THE EQUIPMENT.