



Product :Mojo

Model :CPM0001

Starting Out

Charging your Mojo:

Plug the included micro USB chord into your Mojo and plug the other end into a computer or use the adapter to plug it into the wall. The LED light will turn on red when charging. The LED will flash red when the battery is low.

It is recommended that you charge your Mojo before use.

Connecting your device:

Connect with the Mojo speaker wirelessly via Bluetooth or by using the included 3.5mm auxiliary cable (headphone jack).

Connecting Wirelessly:

Turn on: Press and hold the button for 2 seconds until you hear a beep and the light turns on.

Pair your device: Press and hold the button again for 3 seconds until the LED light indicator begins flashing blue and red. The Mojo is ready to pair.

Turn on your devices' Bluetooth setting.

Connect to the Mojo. Go to your devices settings and search or add devices.

Select "CoverPlay" when it appears on your device.

The indicator light on the Mojo will turn solid blue when it has connected.

Enjoy great sound. Volume is controlled by your device. To turn off, simply hold the button for a half second. The LED light will turn off.

You will only need to pair with your Mojo once. After pairing, the Mojo will automatically connect with your device when turned on. Note, your device will need to have its Bluetooth capability enabled.

Connecting With the Auxiliary Cable:

Turn on: Press and hold the button for 2 seconds until you hear a beep and the light turns on.

Plug one end of the auxiliary cable into your device and the other end into the Mojo.

Enjoy great sound. Volume is controlled by your device. To turn off, simply hold the button for a half second. The LED light will turn off.

The Mojo must be plugged in with a 3.5mm auxiliary cable for use in amplifying calls/conversations.

If you receive a call, priority will go to the call and the music or other media playing from your phone on the Mojo will mute. The call is handled on your phone.

On Outside box:

Specifications

Battery Life: About 10 hours at full volume

Output: 85dB at 0.5m

Frequency: 150Hz-20kHz

Dimensions: Height: 7mm Length: .. Width: ..

Weight: 8.8 oz.

Bluetooth Range: 30 ft.

FEDERAL COMMUNICATIONS COMMISSION (FCC) STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, Pursuant to Part 15 the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.