

## **RL-0506AB    MULTI-DIRECTION    WIRELESS    ALARM    SYSTEM**

### **Equipments:**

1. 3×magnet sensor (enclosed 3×LR44 batteries, each sensor with double-side tape.)
2. 1×main unit (enclosed 3×AA batteries)
3. 3×infrared sensor (used 3×AAA batteries, low-power consumption.)
4. 2×remote (enclosed 1×23A battery for each remote.)

### **Usage:**

- Ideal for house, shop, warehouse etc. where anti-theft is needed.
- Suitable for a place with 4doors/windows and 2 passages where anti-theft is needed.

### **Features:**

- On/off state of the main unit can be controlled by remote. The system will alarm sharply when someone intrudes illegally in armed state.
- Magnet sensor and vibrate alarm can send out alarm signal and alarm sharply to frighten away the thief.
- Switch the main unit ON, both the main unit and magnet sensor will alarm when someone intrudes illegally. The intruded zone can be seen from the main unit. On one hand, it can frighten away the thief; on the other hand, the intruded armed zone can be found in time for personal or property safety.
- Up to 4 door/window alarms and 2 infrared sensors can be added.
- The system can work with more than 2 remotes.
- Adopt energy-saving circuit. Batteries for magnet sensor, infrared sensor and remote can work for one year; batteries for main unit can work for 3 months.

### **Installation:**

- Load 3×LR6 batteries.
- Magnet sensor:

The magnet sensor is composed of magnetic bar and sensor, enclosed batteries. Peel off the double-side adhesive tape and stick the magnet sensor on the door or window where anti-theft is needed. Note: Keep clearance within 1cm around the magnetic bar and sensor.

- Infrared sensor

Load 3×AAA alkaline batteries. Install the infrared sensor on the wall of the main passage. Avoid direct sunlight; do not face the glass window; do not face the heat or cold source; do not face the object that swing easily. The best height for installation is from 1.0 to 1.5m. Adjust the angle for best performance.

- Turn the main unit into “Alarm” state, both the main unit and door sensor will alarm when someone open the door/window or enters the sensor coverage area illegally. The intruded armed zone can be seen from the main unit. On one hand, it can frighten away the thief; on the other hand, the intruded zone can be founded in time for personal or property safety.

- Turn the main unit into “CHIME” state, the main unit will ring when someone opens the door/window or enters the sensor coverage area to arouse the householder’s attention.
- The function of switch on the right side of magnet sensor and vibrate alarm:  
RF --- When someone opens the door/window, the sensor will send out alarm signal.  
RF+ALARM --- When someone opens the door/window, the alarm sounds will be heard after two seconds.

OFF	Switch off
RF+ALARM	Alarm signal and alarm
RF	Alarm signal

#### Multi-direction wireless alarm system

- Ideal for house, shop, warehouse etc. where anti-theft is needed.
- Suitable for a place with 4 doors/windows and 2 passages where anti-theft is needed.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER’S AUTHORITY TO OPERATE THE EQUIPMENT.