






nyne

Nyne Mini


EN Bluetooth Speaker Series

EN Quick User Guide

nyne.com




EN Charge the speaker until the  indicator turns from red to green.



EN After power-on, the Bluetooth indicator flashes blue, indicating that the speaker is ready for pairing.

 **Tip:** You can slide the power switch to the **OFF** position to power off.



- EN (1) Connect an auxiliary audio device to the speaker through the supplied 3.5mm audio cable.
- (2) Play and control music on the audio device, and use +/- on the speaker to adjust volume if necessary.

 **Tip:** When the 3.5mm audio cable is plugged, the speaker switches to AUX IN mode automatically. When it is unplugged, the speaker switches back to Bluetooth mode and sets up Bluetooth connection again.

FCC Radiation Exposure Statement


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

nyne

All registered and unregistered trademarks are property of their respective owners.

Nyne Multimedia Inc.

All rights reserved.




- EN** (1) Enable Bluetooth on your device to be paired with the speaker.
- (2) Select 'Nyne Mini' from the available devices (enter the password '0000' if necessary) to start pairing and connection with the speaker.
- (3) After successful connection, the power/Bluetooth indicator turns solid blue and the speaker beeps.

Tips: This speaker supports automatic connection with a previously paired device after power-off and power-on again.

You can press and hold  for more than 2 seconds to enter manual pairing mode. In this way, you can pair the speaker with a new Bluetooth device.

You can press and hold  for more than 10 seconds to clear all paired Bluetooth devices.



- EN** Play music on your device paired and connected with the speaker.

During music play:

- Press **+/-** to adjust volume.
- Press **▶||** to pause or resume music play

Tips: When you make a call or there is an incoming call, you can use the speaker as a speaker phone. Music play is paused during the call and resumed automatically when the call ends.

During a call, you can press **▶||** to end the call.

