# Conducted Test Setup Placement: (Charging mode)




Front View of the Test Configuration




Side View of the Test Configuration

# Conducted Test Setup Placement: (EUT Only)



Front View of the Test Configuration



Side View of the Test Configuration

# Radiated Test Setup Placement: (Charging mode)



Front View of the Test Configuration




Rear View of the Test Configuration

## Radiated Test Setup Placement: (EUT Only)




Front View of the Test Configuration of X-axis




Rear View of the Test Configuration of X-axis

# Radiated Test Setup Placement: (EUT Only)




Front View of the Test Configuration of Y-axis




Rear View of the Test Configuration of Y-axis

## Radiated Test Setup Placement: (EUT only)



Front View of the Test Configuration of Z-axis



Front View of the Test Configuration of Z-axis