





CONTAIN



INTRODUCTION



HOW TO CONNECT

- 1 Long press the power on/off button  and it will be in Bluetooth mode. The Blue indicator flashes.
- 2 Connect to your device
Setting->Bluetooth->Choose device >V1
Connected successfully
Blue indicator steadily on

FUNCTIONS>>>



Note:

1. Short press the Mode switch button, you can switch between bluetooth playing/MICRO SD card playing.
2. If the device is dead, please long press the POWER ON button at least 8 seconds to reset.
3. Answer/reject call button, short press for answering, long press for rejecting.
4. Support MICRO SD card max 32GB.
5. Insert the MICRO SD card, it will play music automatically.

OTHER >>

Charging

Charging via a computer through a USB cable or to buy USB charger separately.

Indicator

Blue indicator flashes	Status of waiting for connecting
Blue indicator remains steadily on	Connected to Bluetooth® source or MICRO SD Card mode
Low power indicator flashes	Battery voltage lower than 3.3V, Red light flashes means your speaker needs to be charged

Red charging indicator light

Note : Your speaker will power off automatically within 15 minutes if you did not pair it with playback devices in order to save energy.

SPECIFICATIONS >>

Driver spec :	Φ40mm 2W/4W
Size :	91.9x89x43mm
Net weight :	122.5g
Frequency response :	150Hz-17KHz
Sensitivity :	80dB
S/N ratio :	≥80dB
Distortion :	≤0.3%
Working distance :	about 33 feet / 10~15m
Bluetooth profiles :	A2DP/AVRCP/HFP
Frequency range :	2.4GHz-2.480GHz
Working current :	≤400mA
Working voltage :	3.3V~4.2V
Charging voltage :	DC 5V
Charging current :	400-500mA

WARRANTY POLICY >>

Your Bluetooth speaker is covered by a limited warranty.

It is backed by 1 year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced under the following conditions:

- *The warranty applies to the original purchaser. Proof of original purchase is required.
- *The warranty does not cover the damage caused by misuse, abuse or improper storage.
- *In no event shall be responsible for any direct, incidental, consequential or other damages of any kind.

WARNING >>



>>> 

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTICE:
Changes or modifications made to this equipment not expressly approved by (manufacturer name) may void the FCC authorization to operate this equipment.

FCC RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure without restriction.

The company reserves the right to the product modification for appearance and function, which is subject to change without prior notice.