
# Vibration alarm



Specification

WIFI: 802.11b/g/n

Network: 2.4GHz

Working voltage: 3V

Decibel: 130dB

Size: 74\*13mm

Standby current: ≤10uA

Working humidity: 95% ice-free

Storage temperature: 0°C ~ 50°C

Low battery remind: 2.3V±0.2V

\_\_\_\_\_\_\_

-----

\_\_\_\_\_\_

\_\_\_\_\_\_

---------

---------

--------

-----

\_\_\_\_\_\_


-----

\_\_\_\_\_\_\_

**■** 02/10 **▶** 

#### How to use

- Pull out the insulation sheet.
- 2. Turn the power switch to "on".
- Press and hold network button for 3s. Led light is flashing quickly and then enter the distribution state.
- Vibration sensitivity adjustment: switch upward, sensitivity increased, switch downward, sensitivity decreased.



#### Installation

- 1. Put the double-sided adhesive tap on the back of the alarm.
- 2. Mount alarm on the window or door with the sticker.
- 3. Wipe the dust and other particles clean with a cleaning sprayer before installation.



# Download App

- 1. ISO iphone: Download "Smart Life" from GooglePlay
- Android: Download "Smart Life" from app store.
- 3. Open the Smart Life app and create a new account.
- Register and log in.

**■** 04/10 **▶** 



#### Connection instruction

Make sure your smart phone connect to the WIFI and open GPS positioning. Only 2.4g WIFI is supported.

- 1. Open the app and Click "Add device", or click "+" in the upper right to add device.
- In the manual interface select "Vibration Sensor(other)" in the list of "security & Sensors" and go to next step.
- 3 Press and hold the network button for 3~5 seconds, the LED green light is flashing guickly.
- 4. Click "Confirm indicator flash" to enter WIFI name and password and then confirm connection.
- After the connection is completed click "complete" on the application interface of the mobile phone and the successful connection will enter the device interface.

**4** 05/10 ▶






#### Linkage Instruction

- 1. Open the "Smart Life" app and click "Smart" at the botton of the interface to enter the setting interface.
- 2. Click "+" in the upper right, the first step selects the automation condition, and the second step set the task.

**4** 06/10 ▶





#### Notification setting

- 1. Select "me" in the lower right of the Smart Life app to enter the account Setting interface.
- 2. Click "Setting" and select "Sound".
- 3. Click "App Notification" to open the "Push message Setting
- Mobile Application management, smart life app "Notification Management" open "Allow notification"

#### Sharing equipment

**■** 07/10 **▶** 

. You can share the vibration door alarm with your family. and they will receive the message of alarm. Select the device on the Smart Life app and click "∠" in

the upper right of the device interface to enter the door alarm interface.

will send a notification to the user's mobile phone through

When the battery power is too low, the new AAA battery

3. When it is necessary to replace the battery, in order to get

the best battery life, please replace the two AAA batteries

together. The replacement doesn't delete the door alarm

Install the battery in the correct polarity. Incorrect

**■** 08/10 **▶** 

Low Battery & replace battery

should be replaced in time.

Use a properly sized AAA battery.

polarity may damage the alarm.

Battery Notices

3 Select "Share Device" click "Add Share" to enter the Shared account, and then press "Complete".

#### FAQ

- I. Connection application failed?

Please make sure if the battery is low and installed correctly.

- 4. Insensitivity when vibrating?
- amplitude is large, switch downward, amplitude is small.

**■** 09/10 **▶** 

# Warranty Card

User name

Model name

Contact add.

Purchase add.

Purchase date.

Cantact

carbon, old and new batteries. Thank you for purchasing our product. Don't try to charge non-rechargeable batteries.

Please fill in the details below and keep them safe. Disassembled the battery put the battery into the fire and throwed battery into the water are not allowed. Old batteries must be disposed of in accordance with local waste recovery regulations.

- a. Make sure that you are connected to a 2.4ghz WiFi network. This device does not support 5GHz WiFi network.
- b. Make sure to connect when the battery is fully charged

3. Do not mix different types of batteries, such as alkaline

- No alarm when vibrating?
- No notification when vibrating? Make sure that the alarm in the Wifi normal transceiver range.

The problem of sensitive selecting, switch upwad, the

**■** 10/10 **▶** 

### **FCC Caution:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **IMPORTANT NOTE:**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

# **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator your body.