

1. External Photograph of EUT

Brand Name: SONY; Model Name: SRH-S1



Brand Name: SONY; Model Name: SRH-S1





Brand Name: SONY; Model Name: SRH-S1





Brand Name: SONY; Model Name: SRH-S1






Brand Name: SONY; Model Name: SRH-S1





Brand Name: SONY; Model Name: SRH-S1





2. Photograph of Accessory

Brand Name: SONY; Model Name: SRH-S1

List of Accessory:

Specification of Accessory				
Battery	Brand Name	TDK	Model Name	PDX-223/224 (SNYHHR7)
USB Cable 1	Brand Name	Chunsheng	Model Name	CA-0207DA14R-05
USB Cable 2 C to C	Brand Name	Chunsheng	Model Name	CA-0207DA07R-05
USB Cable 3 C to A	Brand Name	Chunsheng	Model Name	CA-0207DA09R-05
Controller	Brand Name	SONY	Model Name	SRH-SA2
Dock	Brand Name	SONY	Model Name	SRH-SA3
Ring	Brand Name	SONY	Model Name	SRH-SA1
Fixed strap	Brand Name	NA	Model Name	NA
Mask	Brand Name	NA	Model Name	NA

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: SONY; Model Name: SRH-S1





Brand Name: SONY; Model Name: SRH-S1





Brand Name: SONY; Model Name: SRH-S1







Brand Name: SONY; Model Name: SRH-S1



Brand Name: SONY; Model Name: SRH-S1




Brand Name: SONY; Model Name: SRH-S1





Brand Name: SONY; Model Name: SRH-S1




Brand Name: SONY; Model Name: SRH-S1






Brand Name: SONY; Model Name: SRH-S1





Brand Name: SONY; Model Name: SRH-S1



Brand Name: SONY; Model Name: SRH-S1

