



1. External Photograph of EUT

Brand Name: SONY; Model Name: SRH-SA1



Brand Name: SONY; Model Name: SRH-SA1




Brand Name: SONY; Model Name: SRH-SA1






Brand Name: SONY; Model Name: SRH-SA1



Brand Name: SONY; Model Name: SRH-SA1



Brand Name: SONY; Model Name: SRH-SA1



2. Photograph of Accessory


Brand Name: SONY; Model Name: SRH-SA1

List of Accessory:

Specification of Accessory				
Battery	Brand Name	Springpower	Model Name	731834

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: SONY; Model Name: SRH-SA1



Brand Name: SONY; Model Name: SRH-SA1

