

# Smart IP Cam



## Quick Installation Guide

website: [www.en.sigmacasa.com](http://www.en.sigmacasa.com)

SA-7510

Includes



Package contents ( more accessories under the second layer)



### Proper use

The door/window contact is designed to be connected with the ΣCentral in order to report incidents as soon as a door/window is opened or closed. You can access the reported incidents on the central unit via the app using a smartphone.

### CE declaration of conformity

- Directive 2014/53/EU
- EMC Directive 2014/30/EU
- Low Voltage Directive 2014/35/EU
- RoHS Directive 2011/65/EU

### 第十二條

經型式認證合格之低功率射頻電機、非經許可，公司、商號或使用者均不得擅自變更頻率、加大。

### 第十四條


低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾；功率或變更原設計之特性及功能。


English



- Download ΣCasa APP from APP Store or Google Play.
- Register an account for your ΣCasa.



- Follow the instruction on APP to add and pair device.




- Please make sure the distance between ΣCentral and other devices is less than 10m.
- Write down PinCode number on ΣIP Cam device. Use a pin to press the reset button in the front and hold for 3 seconds until the LED flashes.



- 下載ΣCasa應用程式，掃描左方QR Code或在APP Store/Google Play搜尋“Sigma Casa”。
- 下載完成後，在APP中註冊一個ΣCasa帳號。



- 進入ΣCasa APP「設定」裡的「新增裝置」，開始進行ΣIP Cam 配對。




- 先將ΣIP Cam 上的PinCode號碼記下來。
- 請用針刺ΣIP Cam 的重置針孔三秒，直到LED燈閃爍為止。



- Laden Sie die ΣCasa APP aus dem APP Store oder bei Google Play herunter.
- Registrieren Sie sich bei ΣCasa.



- Folgen Sie den Anweisungen in der APP um Geräte zu verbinden und hinzuzufügen.




- Bitte stellen Sie sicher, dass die Entfernung zwischen ΣCentral und anderen Geräten ist weniger als 10m.
- Notieren Sie die PinCode-Nummer auf ΣIP Cam Gerät. Benutze einen Stift, um die Reset-Taste vorne zu drücken und für 3 Sekunden zu halten, bis die LED blinks.



- APP StoreかGoogle Playから専用アプリ「Casa」をダウンロードしてください。
- インストール完成後「Casa」のユーザー登録を新規登録してください。



- アプリの案内に従ってΣCentralとペアリングしてください。



- ΣIPCamにPinCode番号を書き留めます。
- LEDが点滅するまで針ΣIPCamでピンホールを3秒間リセットしてください。



FCC Caution:

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.