

Operation Description

1. Transmitter could get power supply by Auto Power Cord from your car cigar plug.
2. Turn on the ON/OFF boot and inter FM launch, insert an external audio source (with an external 3.5-inch audio interface, or by ipod's special input audio).
3. Press the frequency boot to regulate frequency, Regulate UP / DOWN boot, the frequency turned forward or backward 0.1MHZ every time you press the upper or lower boot.
4. The transmitter's output FM channel is from 88.1 to 107.9MHZ with a 100KHz step.
5. The transmitter can charge the ipod when inserted it.
6. With remote control.
7. The USB port can charge the external product which has normal USB port.