


DPV-156 FM Transmitter circuit block diagram



NOTE :

Y 1 frequency of oscillator □ 32.768 kHz

Y 2 frequency of oscillator □ 4 MHz

Y 3 frequency of oscillator □ 38 kHz