


## User Manual

### ***Input:***

Electronic ballast output Volt: 120V , 60Hz

### ***Wiring:***



### **Circuit Description**

When the lightness inside or outside is just like the daytime, negative ionic light is lightless; When the it is dark, the night light use photo sensor to control negative ionic light, and make the night light work on effective time, negative ionic light is luminescence, which can be used as light, at the same time, negative ionic generator start work. Negative Ionic light's LED can be used over 4000 hour, while negative ionic generator is over 1000 hour, Negative Ions Output: > 2000,000 ions/cc

### **Ionizer Description**

The air inside your car may likely contain pollutants or impurities such as pollen smog, exhaust, dust or bacteria. Use the Ion Care Plug-In Ionizer to clean and freshen up the air you breathe inside your vehicle, Carbon Fiber Ionizer generates trillions of negative ions to revitalize the air, Negative Ions Output: > 2000,000 ions/cc; Effective Area:  $\leq$  15 cubic meter

### **FCC Note:**

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modification could void the user's authority to operate the equipment.

This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30 MHz.