

EUT Internal Photos

Figure 4
Internal View (Remove Cover)



Figure 5
Internal View (Remove RF Board & Main Board)




Figure 6
Internal View (RF Board & Power Board, Front View)




Figure 7
Internal View (RF Board & Power Board, Back View)




Figure 8
Internal View (Main Board & Battery)



Figure 9
Internal View (Main Board, Front View)




Figure 10
Internal View (Main Board, Back View)

