


MANUAL



1. LED Clock
2. On /Off Switch
3. Forward
4. Play / Phone / Set
5. Backward
6. Light switch
7. Charging light
8. Bluetooth light
9. Mic
10. Power sources :AA battery / Rechargeable battery switch
11. USB Jack
12. Speaker
13. Mirror
14. Back stand
15. Battery compartment
16. Light

Rechargeable Battery Charging (USB Jack)

Flip switch down  to Rechargeable battery (10) , connect the



USB cable (included) to a PC computer or charger (5V) the other end into unit USB jack (11) , Charging light will red , fully charging will off red.

NOTE: No power of battery will said “ no battery , please charge “ or “ power off ” .

Battery (AA /UM3)

Flip switch up  AA battery (10) and put the batteries AA/UM3 X 4 pieces into Battery Compartment (15) (Battery not included)

How set the clock

Turn the unit to “OFF” position, before setting the clock,(clock cannot be set when unit is in “ON” position).

1)Press the  (4): to show digit in clock.

2)Long press  (4) 12H flash, press  (3)or  (5) to select 12/24 Hour.

3)After 12/24Hr is select, press  (4) to confirm
'Hour' flash press  (3)or  (5) to set the Hour , press  (4) to confirm
'Minute' flash.  (3) or  (5) to set the Minute , press  (4) to confirm.

Note :A) After 1 second ,clock will return to normal, has to repeat step 3.

B)After clock is set , clock will auto-off within 30 minute ,press either :

 (3) ,  (4),  (5) or light(6) to turn “ON”the clock display.

C) When AA battery or Li-ion battery no power , clock will default setting.

Light (6)

When LED clock to ‘ON’ , Press Light switch (6) to turn “ON” the light, press again to turn “ OFF ”.

Bluetooth

Press On/Off Switch(2) repeatedly until Bluetooth function of a mobile phone or an audio player, then scan and pair with this speaker (1703BT). A short tune will sound if connection is successful.

Set the mobile phone or audio player to play the musicfile.Press  (4) to play/pause, press  (3) or  (5) to play the previous or the next music file, longpress  (3) or  (5) to adjust sound volume.

When music (from mobile phone) is playing through the speaker, beeps will sound to alert an incoming call. Press  (4) to answer (hands-free) the call, press  (4) again to end the call. After telephone conversation, unit will return to wireless speaker function. Turn “OFF” unit when not in use by pressing “ON/OFF” switch (2).

Content

- Batteries requires 4 x AA batteries, 1.5V (Not included)
- Built in rechargeable Battery 3.7V/1800 mAh
- USB Cable for charging (Included)
-

Caution :

- Only clean the mirror by soft cloth, Any solvent which contained alcohol or thinner are not accepted.
- Anti-fog function will be weakened by cleaning frequently.

Specification :

Supply Voltage :5V, USB charging

Bluetooth : Version 5.0

Remark :

The rubber cover for (10) and (11) must be placed in right position to prevent water to go inside the unit.

Battery door of the battery compartment must be placed in right position and rotate the “knob” to vertical position to prevent water to go inside the unit.

Unit is shower resistance, do not drop unit inside bathtub or water tank.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible

for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.