

APPLICANT: EASTERNTRONIC LCD GROUP

FCC ID: T55060101

# Car Lover User Manual

## On-board Wireless Player

## Keys Description

- 1.1 PLAY key:
- Under normal play status, press this key to pause, and again to resume. Under active status, press and hold this key for 3s to shutdown, and to start up under shutdown status.
- 1.2 Functional key (FUC)
- 1.2.1 Under normal play status when the screen is in normal display, press this key to enter play mode adjusting status, under which the icon of play mode flickers;
- 1.2.2 Under play mode adjusting status, press this key to enter sound effect mode adjusting status, under which the sound effect icon flickers per second;


- 1.3 “-” key
  - 1.3.1 Under normal play status, short press this key to select previous song, and long press to reduce volume;
  - 1.3.2 Under play mode adjusting status, press this key to enable RPT1—PRTALL—RND—NORMAL loop;
  - 1.3.3 Under sound effect mode, press this key to switch sound effects.
  - 1.3.4 Under frequency adjusting status, press this key each time will reduce frequency by 0.1MHz, and hold it to reduce frequency quickly;

1.3.5 Under music selection status, short press to play previous song and long press (above 2 seconds) to activate quick locating function. If some values are changed during adjusting, press the FUC key to return to prior menu, and again to skip to next adjusting item. If certain status has been specified for a song or there is no key operation within 5s, the Player will return to play status.

- 1. 4 “+” key

The function of “+” key is similar to that of number key 3, but the adjusting function is reverse.

# LCD Display



Song number

Current song

Play mode

Volume

Sound effect mode

USB access instruction

Battery capacity

Play mode adjusting

Play time

Transmission frequency

- 2.1.1、Icon of repeating one, RPT1.
- 2.1.2、Repeat all, RPTALL.
- 2.1.3、Random play, RND.
- 2.1.4、Icon of normal play mode, NORMAL, namely play the first song to the last one.
- 2.2、Sound effect mode
- 2.2.1、Rock &Roll play mode, ROCK
- 2.2.2、Jazz play mode, JAZZ
- 2.2.3、POP play mode, POP
- 2.2.4、Natural play mode, NAT

# Features

- 1、 Use MP3 as source, without problems such as vibration and disc scratch.
- 2、 Smart appearance, wide LCD display, compact keys, easy to use and carry, and designed for drivers.
- 3、 Receive signals through FM radio, no need to change audio system on your motor.
- 4、 Transmission frequency of 88-108MHz can be adjusted by 0.1 MHz as necessary to avoid interference from local radio.
- 5、 Four sound effect modes available: Natural, Pop, Rock & Roll and Jazz.

# Wireless Transmission

- 4.1、 Set the frequency at 88-108MHz and the radio at the corresponding frequency to receive.
- 4.2、 In order to avoid interfering and disturbing others, please select a transmission frequency not covered by local radio station.
- 4. 3 Press and hold function key FUC to enable/disable wireless transmission function.

# Important

- 5. 1、Please use the charger provided by us to recharge the battery, otherwise the Player may be damaged. You can also recharge through PC USB interface. If the host cannot provide 500mA currency, do not use PC to recharge.
- 5. 2、Do not turn the volume high when you are driving to avoid detracting.
- 5. 3、Do not place the Player under extended exposure to sunlight, or in high temperature or humid environment.
- 5. 4、Do not drop the Player or make it receive strong vibration. Normal car environment will not cause damages.
- 5.5、When the battery is in low capacity, the battery icon will flicker. The Play will automatically shutdown when the battery is exhausted. Please recharge it before using it again.
- 5.6、Please shutdown the Player in environments that prohibit using wireless equipment, such as in planes and gas stations.
- 5.7The specification and design of this product is subject to change without notice.

# Specifications

- Size: 43\*55\*92mm
- Weight: 60G
- Display: 41\*41mm LCD segment code
- FM frequency: 88.1-107.9MHz
- Battery duration: 5h under transmission mode and 9h under play mode
- MP3 Format supported: MP3
- Permitted receiving distance: 10m
- Recharge power: DC5V/0.5A+-5%

## Recharge and Back Light

- 6.1、Once the charger is connected, the Player will automatically judge if it is necessary to recharge.
- 6.2、You can also recharge through PC USB interface, simply by connecting the USB cable to PC (do not recharge through PC if it cannot provide 0.5A currency).
- 6.3、If there is no key operation within 10s, the Player will automatically close the back light.

# Outline

LCD screen  
“-”key

FUC key

“+” key

Startup key



APPLICANT: EASTERNTRONIC LCD GROUP

FCC ID: T55060101

FCC NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED  
BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS  
COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.