

WARNING:
CHOKING HAZARD- Small parts.
Not for children under 3 years.



ROCKING RC BLACK PEARL INSTRUCTIONS

Out of the Box:

Remove Rocking RC Black Pearl from the box, carefully collecting and disposing of the packaging properly.

Package Contents:

- Rocking RC Black Pearl
- Skull Remote
- Jack Sparrow Figure
- Barrel
- Cannon

Read instructions before use, and keep for future reference.

IMPORTANT BATTERY INFORMATION:

CAUTION: As with all small batteries, the batteries used with this toy should be kept away from small children. If they are swallowed, promptly see a doctor and have the doctor phone the poison control center. Make sure that batteries are inserted correctly and follow the toy and battery manufacturer's instructions.

- The Rocking RC Black Pearl uses four (4) AA / LR6 1.5V batteries and the Skull Remote uses one (1) 9V/6LR61 9V battery.
- When replacing, replace all four (4) of the RC Black Pearl's batteries at the same time.
- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.
- Do not dispose of used batteries in a fire. This could cause the batteries to explode.
- Battery installation should be done by an adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision (if removable).
- Different types of batteries or new and used batteries are not to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Replace with new batteries at the first sign of erratic operation.

INFORMATION TO USER:

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Carrier frequency: 27.145 MHz, Field strength: 72.6dBuV/m at 3m.

This radiocommunication device complies with all the requirements of Industry Canada Standard RSS-310.

Ce dispositif de radiocommunication rencontre toutes les exigences de la norme CNR-310 d'Industrie Canada.


Meets requirements of European Council Directives 99/5/EC, 89/336/EEC, 88/378/EEC, suitable for use in all EU member states.

Battery Installation:


Caution! Always have an adult perform the battery installation.

1) Using a Phillips head (cross-head) screwdriver, remove the battery covers located on the bottom of the ship and the back of the skull remote.

2) Insert 4 new AA/LR6 1.5V batteries (not included) into the ship and 1 9V/6LR61 battery (not included) into the skull remote. Make sure you install the batteries according to the correct polarity.




Ages 4+
Item no. 03020



3) Replace the battery covers.

To Activate the Rocking RC Black Pearl:


1) To turn the RC Black Pearl ON, flip the switch located on the back of the ship to the left.



2) Point the skull remote towards the RC Black Pearl and press in one of the skull's eyes.

- To make the ship move forward, press the skull's left eye. (a)
- To make the ship change directions, press the skull's right eye. (b)

c. The RC Black Pearl can move on low cut carpeting and hard floor surfaces.




3) To turn the RC Black Pearl OFF, flip the switch located on the back of the ship to its original position.


Note: The Rocking RC Black Pearl is not intended for water play.

Rocking RC Black Pearl Assembly:


1) Place bow sprit into corresponding areas on the front of the ship.




2) Place each anchor into the designated places on the sides of the front of the ship.




3) Place the steering wheel and railing piece into the corresponding holes on the upper deck of the ship.




4) Assemble the front mast: A) Snap one of the two largest sails onto the second tallest mast. The sail should snap in between the bottom two notches on the mast. B) Slide the sail with the longest rigging line attached to it onto the mast. This sail should slide down until it rests above the top notch on the mast. C) Place the entire mast into its designated location on the front deck of the ship. D) Attach rigging line to the bow sprit.




5) Assemble the middle mast: A) Snap the ratlines onto the tallest mast. The ratlines should snap together directly under the crow's nest. The piece that extends out where the ratlines connect should be facing towards the front of the ship. B) Snap the ratline holder onto the piece that extends out where the ratlines connect. C) Take one of the two largest sails and connect it to the mast in between the two bottom notches on the mast. D) Slide one of the two smaller sails that have rigging lines onto the mast. It should rest on the second notch down from the top. E) Slide the flag onto the mast. It should rest on the top notch on the mast. F) Place the entire mast into its designated location in the middle of the ship. G) Attach the ratlines into the sides of the ship. H) Attach the rigging line on the middle sail onto the top of the front mast.





6) Assemble the back mast: A) Snap the triangle shaped sail onto the shortest mast. The sail should snap onto the mast in between the bottom two notches on the mast. B) Slide one of the two smaller sails that have rigging lines onto the mast. It should rest above the top notch on the mast. C) Place the entire mast into its designated location in the back of the ship. D) Attach the rigging line onto the top of the middle mast.



7) Place the cannon and barrels anywhere on the ship.



8) Place the Jack Sparrow figure onto the post behind the steering wheel. Jack can also hang onto any of the rigging lines between the masts.



Warranty Information:

90-DAY LIMITED WARRANTY (For USA Only)

Zizzle, L.L.C. ("Zizzle") warrants to the original consumer purchaser of this product that it will be free from defects in materials or workmanship for 90 days from the date of original purchase. This warranty does not cover damages resulting from accident, negligence, improper service or use or other causes not arising out of defects in materials or workmanship.

During this 90-day warranty period, the product will either be repaired or replaced (at Zizzle's option) without charge to the purchaser, when returned to Zizzle with proof of the date of purchase.

Product returned to Zizzle without proof of the date of purchase or after the 90-day limited warranty period has expired, but prior to one year from the original date of purchase, will be repaired or replaced (at Zizzle's option) for a service fee of U.S.\$25.95. Payments must be by check or money order payable to Zizzle, L.L.C.

The foregoing states the purchaser's sole and exclusive remedy for any breach of warranty with respect to the product.

All product returned must be shipped prepaid and insured for loss or damage to:

Zizzle
6500 26th Street East
Fife, WA 98424
Attn: Returns Department

The product should be carefully packed in the original box or other packing materials sufficient to avoid damage during shipment. Include a complete written description of the defect, a check if product is beyond the 90-day limited warranty period, and your printed name, address and telephone number.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE ZIZZLE IN ANY WAY. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE NINETY (90) DAY PERIOD DESCRIBED ABOVE. IN NO EVENT WILL ZIZZLE BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS PRODUCT.

Some states do not allow limitations as to how long an implied warranty lasts and/or exclusions or limitations of incidental or consequential damages, so the above limitations and/or exclusions of liability may not apply to you. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.



©2007 ZIZZLE
Zizzle, L.L.C.
Bannockburn, IL 60015
U.S.A.

MADE IN CHINA All Rights Reserved

Meets or exceeds all safety requirements of ASTM F963.



Printed in China
209-00261-02