




Figure 1 - Internal Photo - Back




Figure 2 - Internal Photo - Front



Figure 3 - Back of EUT showing location of screw near antenna



Figure 4 - Location of screw next to antenna (Measurements shown in centimeters)