

# Manual

## Product introduction

- For use in vehicle or home
- Supports all type of portable audio /video devices MP3/MP4 Players CD Players etc
- With 3.5mm Audio connector to Plug your MP3/MP4 and other Audio Players
- With a DC pin to connect the car socket and get power from car
- With 4 groups fixed frequencies to be adjustable

## Users Guide

- Connect FM Transmitter into your Car Cigarette Lighter Jack
- Connect the Transmitter input Jack to your Portable Device output jack
- Tune the Frequency of your FM Radio in your Vehicle to the same Frequency on your FM Transmitter
- To obtain good reception please tune both your Vehicle FM Radio Frequency &your FM Transmitter Frequency to the best possible frequency for clearer sound
- For Home Use place 2\*AAA Batteries into the battery compartment at the back of the unit .Follow the same above procedure connecting your transmitter to your Portable device

## Warnings:

Do not mix alkaline,standard (carbon-zinc) or rechargeable (nickel cadmium) batteries.

Do not mix old and new batteries.

Do not dispose of batteries in a fire.

Do not attempt to recharge ordinary batteries.

Batteries may explode or leak

FCC NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER ' S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation