


FM WIRELESS TRANSMITTER OPERATION MANUAL



Product Introduction

- For Use in Vehicle or Home
- Supports all type of Portable Audio/Video Devices MP3/MP4 Player, CD Players etc. Equipped with a 3.5mm or 2.5mm output jack.
- Digital Read out Frequency and Blue Back Light LCD Display.
- 9 Group Preset Frequency Memory Stations
- Auto Shut off Function when transmitter is not in use for 30 seconds.

Users Guide

- Plug the FM Transmitter into your car Cigarette Lighter.
- Connect the Transmitter input Jack to your Portable Device output jack.
- Turn the Frequency of your FM Radio to the same frequency of your FM Transmitter.
- To obtain good reception, please tune both your FM Radio's Frequency & your FM Transmitter Frequency to the best possible frequency for the clearer sound by pressing the memory key for a few seconds.
- Save your desired Frequency on your FM Transmitter for Easier Use next time.
- For Home Use, place 2*AAA Batteries into the battery compartment at the back of the unit and switch the 12V to 3V. Follow the same above procedure connecting your transmitter to your Portable device.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.