


# Switch™ Fob

## Operating Instructions

### OVERVIEW

**Compatible Devices:** Android™ 5+ iOS: 11.0+


**A** Front Cover



**B** Battery (CR2032)




**C** Back Cover



### Synchronize With Mobile Device

#### 1 INSTALL MOBILE APP/ REGISTER PHONE NUMBER

+1 XXX-XXX-XXXX




**NOTE:** If **step 1** has been completed, proceed to **step 2**.

To download the Switch™ mobile app, open the App Store or the Play Store. Browse for the Switch™ mobile app and then select and tap the app to install.

Launch and register with your phone number.

## Synchronize With Mobile Device

### 2 TAP FOB ICON




Fob

Tap the Fob icon.

### TAP SYNC BUTTON


Sync



Tap the Sync button.

### 3 INITIATE PAIRING OF FOB AND MOBILE DEVICE


Press and hold the fob button for **THREE** seconds.



**NOTE:** When pairing a fob with a mobile device, take care that there are no Switch devices nearby, otherwise the fob may accidentally connect to the wrong device.

Press and hold the fob button for **THREE** seconds. The fob and mobile device should begin pairing. The fob LED will appear solid **green** for **ONE** second while searching for a device.

### 4 FINALIZE PAIRING/ REGISTER FOB



**NOTE:** The mobile phone that was used to register the fob will receive notifications of access right updates. See Switch™ Tech user guide for more details.

**NOTE:** A registration token will be provided by the system administrator.

Enter the new registration token when prompted.


Synchronization has succeeded!



**COMPLETE**

## How To Use The Fob

### 1 TOUCH DEVICE THEN PRESS FOB BUTTON TO REQUEST ACCESS



Press the fob button once.

#### Fob LED Status:

- **Green:** Battery OK
- **Red:** Critical battery, Fob may be unregistered.
- **Yellow:** Low battery
- **LED Turns Off:** The LED will light once for **ONE** second and then turn off.


Touch the device (Switch™ Core or Reader). One or more LEDs will indicate the device is awake and ready to interact with a fob.

Press the fob button once to request access while the fob is within the vicinity of the device. The fob LED will appear solid **green** for **ONE** second while searching for a device.

### 2 TURN KNOB TO OPERATE

#### NOTE:

Granting access will engage the knob with the lock but does not physically unlock the lock.



Turn the knob to operate the lock.



**COMPLETE**

### Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### Statement

This equipment has been tested and found to comply with the limits for Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you can try to correct the interference by taking one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Statement

#### **THIS DEVICE COMPLIES WITH INDUSTRY CANADA LICENCE-EXEMPT RSS STANDARD(S).**

Operation is subject to the following two conditions:

- (1) This device may not cause interference and
- (2) This device must accept any interference,

including any interference that may cause undesired operation of the device.

This Class [B] digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

#### **CET APPAREIL EST CONFORME À LA NORME RSS INDUSTRIE CANADA EXEMPT DE LICENCE.**

Son fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences et
- (2) Cet appareil doit accepter toute interférence, y compris les interférences pouvant causer un mauvais fonctionnement du dispositif.

Cet appareil numérique de la classe [B] respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.



**CAUTION:** Before you handle the electronics board or any component connected to it, make sure that you are properly grounded using an electrostatic discharge (ESD) protection kit! Touching the board without proper grounding can damage sensitive electronics components—even if you don't notice any static discharge!



**WARNING:** Changes or modifications not expressly approved by **dormakaba** could void the user's authority to operate the equipment.

## WARNING



**WARNING:** This manufacturer advises that no lock can provide complete security by itself. This lock may be defeated by forcible or technical means, or evaded by entry elsewhere on the property. No lock can substitute for caution, awareness of your environment, and common sense. Builder's hardware is available in multiple performance grades to suit the application. In order to enhance security and reduce risk, you should consult a qualified locksmith or other security professional.



**WARNING:** The fob contains a CR2032 lithium battery. If the lithium battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used lithium batteries away from children. If the fob compartment does not close securely, stop using the fob with the lithium battery and keep the lithium battery away from children. If you think the lithium battery might have been swallowed or placed inside of the body, seek immediate medical attention.



**WARNING:** This product ships with a CR2032 lithium battery. When returning this product, please follow proper lithium battery shipment guidelines.

If you are unsure of the proper shipping guidelines, please remove the CR2032 lithium battery prior to shipping. Lithium batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning battery disposal.



**WARNING: Cancer and Reproductive Harm**  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



**WARNING: Perchlorate Material-special handling may apply**  
<http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

## CAUTION



**CAUTION:** Danger of explosion if the lithium battery is incorrectly installed. Only install a CR2032 lithium battery.



**For Complete Online Instructions Visit: BEST**  
<https://support.bestaccess.com/hc/en-us/articles/360036366673>

Android is a trademark of Google LLC.  
iPhone is a trademark of Apple Inc., registered in the U.S. and other countries and regions. App Store is a service mark of Apple Inc.

**For Assistance or Warranty Information:**  
Call 1-855-365-2407 or visit  
[www.bestaccess.com](http://www.bestaccess.com)