

# JUST KIDZ™

## Portable Walkie-Talkies

FCC ID sticker  
(see next page)



### HOW TO OPERATE YOUR WALKIE TALKIE

1. Open battery cover and snap in a 9-volt battery (not included).
2. Turn the "ON/OFF" switch to "ON" position. Your transceiver is now ready to operate.
3. Press the "PUSH-TO-TALK" switch for transmitting.
4. Release the "PUSH-TO-TALK" switch for receiving.
5. When transmitting, speak clearly in a normal voice, holding the set about 3" from your mouth.
6. Best transmission and reception are obtained when the antenna is held in a vertical position.

### HOW TO USE MORSE CODE FUNCTION

1. For transmitting a signal, turn the "ON/OFF" switch to "ON" position.
  2. While pushing the "PUSH-TO-TALK" button, press in the Morse code button momentarily and release for desired signals.
- The normal function of the product may be disturbed by strong electromagnetic interference. If so, simply reset the product to resume normal operation by following the instruction manual. In case the function could not resume, please use product in other location.

**WARNING:** This device is capable of communicating with CD Radio Transceivers.

- Operating range of up to 100 feet. Operating range can be significantly reduced during indoor use due to interference from electrical equipment such as computers and/or large metallic objects.
- Morse code function included
- To send Morse code, press down the TALK button and Morse code button simultaneously.
- Each unit requires 1 x 9V (6 +LR61) battery (not included).
- Funcionamiento de variedad de hasta 100 pies. El funcionamiento de la variedad puede ser considerablemente reducido durante el uso de interior debido a la interferencia del equipo eléctrico como computadoras y/o objetos metálicos grandes.
- Función de alfabeto morse incluida.
- Para enviar el Alfabeto morse, haga presión en el botón de CONVERSACIÓN y el botón de Alfabeto morse simultáneamente.
- Cada unidad requiere 1 x 9V (6 LR61) batería (not incluido).

FCC statement sticker  
(see next page)

KEEP THE PACKAGING - IT CONTAINS IMPORTANT INFORMATION.  
PLEASE KEEP ALL INFORMATION FOR FUTURE REFERENCE.  
COLOR & DESIGN MAY VARY. PRODUCT SPECIFICATIONS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.  
THIS PRODUCT CONFORMS TO SAFETY REQUIREMENT OF ASTM F963 AND EN71.

CONSERVE EL EMBALAJE - CONTIENE INFORMACIÓN IMPORTANTE.  
CONSERVE TODA LA INFORMACIÓN PARA CONSULTAS POSTERIORES.  
EL COLOR Y EL DISEÑO PODRÍAN VARIAR.  
LAS ESPECIFICACIONES DEL PRODUCTO PODRÍAN CAMBIAR SIN PREVIO AVISO.  
ESTE PRODUCTO CUMPLE CON LOS REQUISITOS DE SEGURIDAD ESTABLECIDOS EN ASTM F963 Y EN71.

Colors and specifications depicted on package may vary slightly from actual product.  
Los colores y las especificaciones representadas en el paquete pueden variar ligeramente del producto actual.

**WARNING:** Wire ties and tags are not part of this toy and should be discarded.

**ADVERTENCIA:** Todas las cintas de goma y cables, así como las etiquetas no son parte de este juguete, y debe deshacerse de ellos.

Made in CHINA for Kmart Corporation  
Hoffman Estates, IL 60179  
SHOP kmart.com




053848FEB12  
0-02355867-9



0 39825 05343 4

FCC ID sticker

letter size 0.8mm



FCC statement sticker

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

letter size 0.8mm

sticker size 20mm X 80mm