



YK-003 Electricity diagram



(1) Sender (AHS001/AHS003)



(2) Receiver (AHR003)