

Roku Relay Product ("Product") Important Product Information

Safety Precautions

Any electrical device, if used improperly, has the potential for causing fire, electrical shock, property damage or personal injury. To help ensure accident-free operation, follow these guidelines:

- Observe all warnings, precautions and instructions.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Stop use, unplug the Product from the electrical outlet immediately, if the Product has been damaged, cracked or punctured, or if the Product functions in an abnormal manner, produces unusual sounds or smells or becomes too hot to touch.
- For more information on product safety and troubleshooting, please go to www.roku.com/support

Use and Handling

- The Product is for indoor use only.
- The Product is not a toy. Keep out of reach of children.
- The Product packaging may include plastic film. Dispose properly and keep out of reach of children.
- The Product should not be exposed to dripping or splashing.
- Do not submerge in water or allow liquid to get into the Product.
- Do not touch the Product during an electrical storm.
- Do not expose the Product to high temperatures, high humidity, direct sunlight, heat sources, smoke or steam.
- Do not drop, crush or disassemble the Product.
- Do not attempt to repair the Product yourself. Disassembling the Product may cause damage not covered by the warranty.
- Dispose of the Product according to local standards and regulations.

The License Agreement

Use of the Product constitutes your agreement to the software license terms for the Product at www.roku.com/legal and the limited warranty set forth below for your country. If you disagree and you are within the allowable time period for returns under the return policy applicable

Need more help getting started?

go.roku.com/relaysetup



Video
tutorials



Wireless
help

to your Product, you may return the Product to the place where you obtained it for a refund, subject to the terms of the applicable return policy.

Limited Warranty & Warranty Service Process

Limited Warranty

For any Product purchased and delivered to end users in the US, go to www.roku.com/support for the warranty terms and conditions. You may also request a copy of such terms by mail by contacting us at 150 Winchester Circle, Los Gatos, CA 95032.

Additional Legal Notices

Federal Communication Commission Interference Statement


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user.



Roku Relay™

Quick Start Guide

Roku



© 2019 Roku, Inc. All rights reserved. ROKU, ROKU RELAY, and the ROKU logo are the trademarks of Roku, Inc. The Bluetooth word mark and logos are trademarks of Bluetooth SIG, Inc. Use by Roku, Inc. is under license.

Meet your new Roku Relay

Front view

Reset
button

Status
button

Back view

Speaker

Plug
prongs



1. Power it up

- For the best streaming experience, find a power outlet that is about halfway between your wireless router and your Roku device.



- Plug in Roku Relay.

Wait 30 seconds until the LED status light turns solid orange, then proceed to Step 2.

For connection help:
go.roku.com/relayhelp



2. Roku Relay mobile app

- Connect your smart phone to your home wireless network.
- Enable Bluetooth® on your smart phone.
- Download the latest version of the Roku Relay mobile app.

TIP: Type “Roku Relay” in the search bar to find the app quickly.



3. Set up using the app

- Open the app and follow the steps to complete setup.

NOTE: You should be in same room as the Roku Relay when setting it up.

For mobile set up help:
go.roku.com/relaysetup

Happy Streaming™