



Operational Description

I . Setting up Your PC Software (Windows Only)

The Windows display-settings for a typical computer are shown below. But the actual screens on your PC will probably be different, depending upon your particular version of Windows and your particular video card. But even if your actual screens look different, the same, basic set-up information will apply in almost all cases. (If not, contact your computer manufacturer or your dealer Dealer.)

1) On the windows screen, select in the following sequence : Start → Settings → Control Panel.

2) When the control panel screen appears, click on Display and a display dialog-box appear..

3) Select the Settings tab in the display dialog-box.

4) The two key variable that apply the television-PC interface are “Resolution” and “Colours”.

Size (sometimes called “Resolution”)

1024X768 pixels

Colour

. 1 billion colours.

Shown at left is a typical screen for “Display” dialog box.

If a vertical-frequency option exists on your display settings dialog box, the correct Value is 60Hz. Otherwise, just click OK and exit the dialog box.