



Turning the Handsfree On and Off

Press and hold the Button-1 for 8 seconds. The LED will flash blue.

Turning Off the Handsfree

Press and hold the Button-1 for 4 seconds. The LED will flash green.

Pairing Your Handsfree

Prior to using your Blue to the Handsfree SOLA-HF668 for the first time, You must Pair it with a Bluetooth-enabled mobile phone.

Place the handsfree and the mobile phone where they are easily viewable by no more than 1 meter.

Activate your mobile phone Bluetooth function by referring to your mobile phone user guide for details.

Ensure the handsfree is OFF. Press and hold the Button-1 until the handsfree LED alternately flashes blue and green.

Scroll to the submenu where a list of all Bluetooth devices are displayed and Select SOLA-HF668

Enter the passkey "1234" to pair your handsfree and mobile phone, the handsfree LED will flash blue.

IMPORTANT If the pairing cannot be completed within minutes while the pairing Mode is activated, turn OFF the handsfree then repeat above step to pair the handsfree and the mobile mobile phone again.

Adjusting the Volume

Press the Volume Key repeatedly until you reach desired volume level.

1

Made Call: Simply make call on your mobile phone in the normal way.

Ending Call: Press the Button-1 once to end your call or end the call via your mobile Phone in the normal way.

Answering Call: To answer call, wait for handsfree to ring, the press the Button-1 once to accept the call.

Voice Dialling from your handsfree: if your mobile phone is equipped with voice dialing function, simply press the Button-1 once, then say the voice tag.

Last Number Redialling from your handsfree: Press and hold the Button-1 5 seconds.

Charging Your Handsfree

The Bluetooth Handsfree SOLA-HF668 comes with a built-in rechargeable battery. Prior to using the handsfree, it is recommendable to charge the battery fully for the first time. Connect the charger to an AC wall outlet and the charger plug to the handsfree's charging socket. The LED will be green while charging.

IMPORTANT: Charging indication will be delayed for a few minutes if the handsfree not been used for a long time or the battery is drained.

Charging Time: Charging the battery fully is with 3 hours. When the battery is fully charged, the LED will turn off.

Talk and Standby Time: The fully charged battery offers up to 4 hours talk time and up to 120 hours standby time. When no calls are in progress, the handsfree remains turned on in standby mode.

2

Safety Information

Check local laws regarding use of a mobile handset and handsfree while driving. If you use the handsfree while driving, ensure your attention and focus remains on your responsibility of driving safely.

Never allow children to play with the handsfree-small parts may be a choking hazard.

Observe all signs that require an electrical device or R.F. radio product to be switched off in designated areas. These could include hospitals, blasting areas, and potentially explosive atmospheres.

Turn off your handsfree prior to boarding and aircraft. Do not use your handsfree in an aircraft.

Never mount or store your handsfree over any airbag deployment area as serious injury may result when an air bag deploys.

Do not open or mutilate the built-in battery.

3

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION.