



<p>dexim® www.dexim.net</p> <p>dexim is a trademark of Santom Limited. The Bluetooth® word mark and logo are registered trademarks and are owned by the Bluetooth SIG, Inc. Samsung is a registered trademark of Samsung Electronics Co., Ltd. All other registered and unregistered trademarks are the property of their respective owners. Visit www.dexim.net or call (1) 888-445-5655 for more information.</p>	<p>dexim®</p> <p>ClickStik™ Bluetooth Remote for Andriod</p> <p>Model# DVA009</p>	<p>Features:</p> <ul style="list-style-type: none"> • Easy-to-use Bluetooth remote puts you back in the group shot when snapping photos • Powerful Free App from the iTunes App Store allows you to edit photos and send to friends via Facebook, SMS, Twitter, QQ, Sina Micro-blog and Email <p>Contents:</p> <ul style="list-style-type: none"> 1 x ClickStik Bluetooth Remote Control 1 x Micro USB cable <p>Product layout:</p>  <p>ClickStik Bluetooth Remote Control Micro USB cable</p> <p>-1-</p>	<p>Specifications:</p> <p>Executive Standard: Bluetooth SIG, V3.0 Bluetooth Protocol: HID Communication Speed Rate: Bluetooth 3.0, Class2, 2M Modulation System: G FSK Communication Distance: 5m open space, Class 2 level Operating Temperature: -10~50°C Storage Temperature: -20~80°C Size: 49.8x17.4x17.4mm Weight: 10g Compatibility: All smartphone supported by Andriod 2.3 or later.</p> <p>Instructions:</p> <p>Pair ClickStik Bluetooth Remote Control to your device</p> <ol style="list-style-type: none"> 1. On your device, open your "settings" and select "general" in the menu. 2. Select "Bluetooth" option in your general settings menu and make sure Bluetooth is turned ON. 3. Take the ClickStik Bluetooth Remote Control and depress and hold the top button down for five (5) seconds or until you see the embedded LED light alternately flashing blue and yellow. Once the LED light is flashing blue, let go of the button. You are now in "Bluetooth Pairing Mode". 4. On your device, you should see your ClickStik DVA009 appear in your "Devices". 5. The ClickStik will automatically connect to your device and will show a status as "Connected". 6. Press your device "home" button to exit your Bluetooth settings. 7. You have now successfully completed the Bluetooth pairing process. <p>-2-</p>	<p>Downloading and Using the Free ClickStik App</p> <ol style="list-style-type: none"> 1. To download and install ClickStik application, launch the iTunes App Store and search for ClickStik from dexim. 2. Install the ClickStik App to your device. 3. Once the ClickStik App is installed on your device, tap the ClickStik App icon to open it. 4. From the ClickStik App home screen you will see two options, "Camera" and "Album". Touch the Camera icon. 5. If your device has a flash, in the upper left corner of your screen there is a "Flash" setting option. Touch the Flash icon and select your flash preference to "Off", "Auto" or "On". 6. If your device has two camera lenses, in the upper right hand corner is the setting for the front-facing camera or the rear-facing camera. Toggling between these two cameras can be achieved easily through this setting. 7. A zoom lens option is available along the right side of the ClickStik Camera screen, ranging from 1.0x zoom to 5.0x zoom. 8. When you are ready to snap a photo, use the ClickStik Bluetooth Remote and depress the top button to activate the camera shutter. Once a photo is taken, it will automatically save it to your camera roll.  <p>-3-</p>
---	---	--	--	---

<p>Finding and Editing your Saved Photos in the ClickStik App</p> <ol style="list-style-type: none"> 1. Locate the icon on the bottom left corner in Camera Mode of the ClickStik App and touch the icon. 2. Touch the "Camera Roll". 3. Select the image you wish to edit. 4. Move and Scale the image to the desired location and size as you wish. 5. ClickStik App offers a range of photo editing software: <ul style="list-style-type: none"> - Mode enables you to use filter effects - Photo Frame enables you to add picture frames - Stamp enables you to stamp your photos with cool stamps (use the scrolling sizer below to enlarge or shrink your stamp size) - Pen enables you to write messages in many colors - Roller enables you to roll patterns on your photos (use the scrolling sizer below to enlarge or shrink your stamp size) - Text enables you to type messages on your photos in many different colors 6. When you have finished editing your photo, touch "Complete" in the top right hand corner of your App screen. You can either "Save" your photo or "Send" your photo. 7. If you wish to "Send" your photo, you send via Facebook, Twitter, QQ, Sina Micro-blog or Email. You must have already set up your Facebook, Twitter, QQ, Sina Micro-blog and Email accounts in order for ClickStik to recognize and send your photos. <p>-4-</p>	<p>Charging for ClickStik Bluetooth Remote</p> <p>Connect the Bluetooth Remote Control with Micro USB cable, and connect the other end of the cable to any powered USB device to charge.</p>  <p>* When the battery is low power, the red indicator will flash one time per second reminder you to recharge. * That's about 90 minutes of charge time to power an ClickStik to 100% capacity. * If the environment temperature is pretty high,please don't charge. * Keep your ClickStik out of direct sunlight and heat sources when Charging.</p> <p>-5-</p>	<p>WARNING! IMPORTANT SAFETY INSTRUCTION!</p> <p>Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard, causing serious and/or fatal injury and/or property damage.</p> <ol style="list-style-type: none"> 1. Do not modify, disassemble, open, drop, crush, puncture or shred the product 2. Do not expose the product to rain or water 3. Keep away from open flame or sunlight to prevent heat build-up 4. Keep away from high voltage devices 5. This product is not a toy. Keep away from children. Ensure that all persons who use the product read and follow these warnings and instructions <p>* For technical support and more information, please email at support@dexim.net.</p> <p>-6-</p>	<p>FCC Compliance Statement</p> <p>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Important: Any changes or modifications to this unit not expressly approved by the party responsible (dexim) for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and the receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. <p>-7-</p>	 <p>European Union-Electronics and Battery Disposal Information</p> <p>This symbol means that according to local laws and regulations your product and its battery should be recycled separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities for the recycling of electronic equipment. The improper disposal of waste electronic equipment from the consumer may be subject to fines. The separate collection and recycling of your product and its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service, or the shop where you purchased the product.</p> <p>FC R&HS CE</p>  <p>Waste electrical products/batteries should not be disposed of with household waste. Separate disposal facilities exist, for your nearest facilities.</p> <p>-8-</p>
---	--	---	--	---