



Once on, the Red LED indicator will turn on solid and the Yellow LED indicator will begin to flash.



Plug in the video BNC for composite video.



Connect XLR audio cables and power source.



## 8.2 TRANSMITTER:



Place the transmitter on the back of the camera.

Screw on antennas and position so they will bend back if knocked.



Clip camera battery on back of transmitter.



Turn transmitter on.

The LED will turn RED, and the yellow LED will flash. This indicates that the transmitter is searching for its paired receiver. This can take up to one minute in very high interference or congested areas.

Once the units are locked, a solid RED, solid YELLOW, and a GREEN slow-blinking LED will be displayed. This indicates that the system is working but there is no video being received by the transmitter.