

User's Manual – Predation Remote Control

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- (3) This device can automatically deactivate the transmitter within not more than 5 seconds of being released.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The Device Data:

1. Model designation: Predation
2. Power: 3V battery
3. Frequency: 433 MHz

Operation instruction:

Step:

1. Switch on the call unit by pressing ON/OFF button.
2. Put the call unit away from the remote control unit up to 250 feet
3. Push the PLAY button on the remote control unit. The LED on the remote control will light indicating that the remote control is working when a button is pushed. The remote control will not work if two or more buttons are pushed at the same time.
4. The call unit will sound when the PLAY button on the remote control is pushed. Once the button is released the sound will not stop until the sound cycle ends.
5. The volume of the control unit is controlled by the “VOL UP” and “VOL DOWN” buttons on the remote control unit. The LED light will light to show that the remote control unit is working when a button is pushed.
6. Press the PAUSE button to pause the sound. Pressing the PAUSE button again will cause the sound to continue. The LED light will light to show that the remote control unit is working when a button is pushed.
7. Press the NEXT button to step up to the next recorded sound. Press the PREVIOUS button to step down to the next recorded sound. The LED light will light to show that the remote control unit is working when a button is pushed.
8. Press DECOY button to power on/off accessory decoy items. The LED light will light to show that the remote control unit is working when a button is pushed.
9. Press REPEAT button to continuously play a selected sound. Pressing the REPEAT button a second time will turn off the continuous play feature. The LED light will light to show that the remote control unit is working when a button is pushed.
10. When finished using the remote control unit, do not forget to turn the call unit off by pressing the ON/OFF button. The LED light will light to show that the remote control unit is working when a button is pushed.