

1. Photographs of Conducted Emissions Test Configuration - USB mode





Under table view

2. Photographs of Conducted Emissions Test Configuration - Adapter mode


Front view



Side view




Under table view




3. Photographs of Radiated Emissions Test Configuration - USB mode

For radiated emissions 30MHz~1GHz

Front view




Rear view



For radiated emissions above 1GHz

Front view




Rear view



4. Photographs of Radiated Emissions Test Configuration - Adapter mode

For radiated emissions 30MHz~1GHz



—————THE END—————