


LiteSounds

LS2400-RC Manual

Operating the Remote

This wireless remote device controls the volume of the LiteSounds LS2400-XP wireless receiver. There are four sound level settings. Press the “Arrow Up” key to the adjust sound to the first level setting. The LED should turn on. Repeatedly press “Arrow Up” key to increase sound volume. Press the “Arrow Down” to reduce volume. Repeatedly press the “Arrow Down” key to decrease sound volume.



Installing Batteries

1. Remove the battery compartment cover on the back of the remote control.
2. Check the battery polarity carefully and install the battery as shown.
3. Replace the battery compartment cover.



NOTE* Use only NO. 27A replacement battery.

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.