



Lock
Verrouiller
Bloqueo



Camera
Caméra
Cámara



Power button
Bouton d'alimentation
Botón de encendido




AC adapter port
Port de l'adaptateur c.a.
Puerto de adaptador de CA



USB ports
Ports USB
Puertos USB



Headphone jack
Prise de casque
Conexión de auriculares



support.microsoft.com

 Microsoft Surface Laptop SE



© 2021 Microsoft.