

EUT Internal Photos

Figure 12
General Appearance, Internal View



Figure 13
Internal View (Removed Cover)




Figure 14
Internal View




Figure 15
I/O Port Board, Front View




Figure 16
I/O Port Board, Back View




Figure 17
Camera Board, Front View




Figure 18
Camera Board, Back View




Figure 19
Internal View




Figure 20
Main Board, Front View




Figure 21
Main Board, Back View




Figure 22
11ax RTL8852BE Combo module, Front View



Figure 23
11ax RTL8852BE Combo module, Back View




Figure 24
Battery Pack, Front View



Figure 25
Battery Pack, Back View



Figure 26
Internal View




Figure 27
WLAN Main Antenna (Back View)




Figure 28
WLAN Main Antenna (Front View)




Figure 29
WLAN AUX Antenna (Back View)



Figure 30
WLAN AUX Antenna (Front View)

